


Pleasant Hearth[®]

Log Holder

Model #923



⚠ WARNING

- Do not allow children to play with or around the log holder.
- Do not place the log holder too close to the fireplace.
- Do not place hot particles in the log holder.


CARE AND MAINTENANCE

- Use a soft cloth to wipe the log holder.
- Store in a clean, dry place.
- Do not use abrasive cleaners as they may cause parts to tarnish or rust.

Pleasant Hearth®

Leña Titular

Modelo #923



▲ ADVERTENCIA

- No permita que los niños jueguen con o cerca de leña titular.
- No coloque el soporte de leña titular demasiado cerca de la chimenea.
- No coloque partículas calientes en el soporte de leña titular.


CUIDADO Y MANTENIMIENTO

- Utilice un paño suave para limpiar el soporte de registro.
- Almacene en un lugar limpio y seco.
- No use limpiadores abrasivos, ya que pueden causar que las partes que empañan ni se oxida.

Pleasant Hearth®

Porte-bûches

Modèle N° 923



⚠ AVERTISSEMENT

- Ne laissez pas les enfants jouer avec le porte-bûches ou à proximité.
- Ne placez pas le porte-bûches trop près du foyer.
- Ne placez pas des particules chaudes dans le porte-bûches.

ENTRETIEN

- Utilisez un chiffon doux pour essuyer le porte-bûches.
- Rangez-le dans un endroit propre et sec.
- Ne pas utiliser de nettoyeurs abrasifs car ils peuvent causer des parties à ternir ou rouille.