


REPLACEMENT PARTS - MODEL RM4625

2-CYCLE GAS CULTIVATOR

PPN 21AK125G983




| Item | Part No. | Description | Item | Part No. | Description |
|------|------------|---------------------------------------|------|------------|--|
| 1 | 791-181345 | Screw | 21 | 753-06841 | Shortblock (includes 4, 5, 19, 22, 23, 24) |
| 2 | 753-06833 | Housing, Rear (includes 1, 18 and 37) | 22 | 753-06840 | Module |
| 3 | 753-06792 | Muffler | 23 | 753-06175 | Flywheel |
| 4 | 753-06193 | Spark Plug | 24 | 753-06247 | Washer |
| 5 | 791-182723 | Screw | 25 | 753-06842 | Housing, Starter |
| 6 | 753-06184 | O-Ring | 26 | 791-181862 | Screw |
| 7 | 753-06189 | Insulator Assembly (includes 6 and 8) | 27 | 753-06218 | Spacer |
| 8 | 753-06185 | O-Ring | 28 | 753-05860 | Clutch Assembly |
| 9 | 753-06190 | Carburetor | 29 | 753-06843 | Clutch Cover |
| 10 | 753-06253 | Gasket | 30 | 791-180217 | Nut |
| 11 | 753-06834 | Air Cleaner Base | 31 | 753-06844 | Bolt |
| 12 | 753-05253 | Screw | 32 | 753-04003 | Screw |
| 13 | 753-06835 | Plate | 33 | 791-181345 | Screw |
| 14 | 753-06836 | Filter | 34 | 753-06845 | Spacer, Rubber |
| 15 | 753-06837 | Air Cleaner Cover | 35 | 791-182612 | Fuel Cap |
| 16 | 753-06838 | Screw | 36 | 753-06846 | Fuel Tank (includes 35 and 39) |
| 17 | 753-06294 | Muffler Screw | 37 | 791-181862 | Screw |
| 18 | 753-06174 | O-Ring | 38 | 791-182405 | Switch |
| 19 | 753-06275 | O-Ring | 39 | 791-181930 | Fuel Tank Screw |
| 20 | 753-06839 | Lead Wire | | | |

REPLACEMENT PARTS - MODEL RM4625

2-CYCLE GAS CULTIVATOR

PPN 21AK125G983



| Item | Part No. | Description |
|------|------------|--------------------------------|
| 1 | 753-06808 | Throttle |
| 2 | 753-04498 | Handle |
| 3 | 753-05940 | Spring |
| 4 | 753-06831 | Throttle Cable |
| 5 | 753-06832 | Cap |
| 6 | 753-04190 | Eyelet Bolt |
| 7 | 753-05527 | Nut |
| 8 | 791-182899 | Bolt |
| 9 | 753-04052 | Washer |
| 10 | 791-182677 | Knob |
| 11 | 753-04060 | Screw |
| 12 | 753-06813 | Bracket, Upper |
| 13 | 753-06809 | Handle |
| 14 | 753-04202 | Bolt |
| 15 | 753-04052 | Washer |
| 16 | 753-04061 | Nut |
| 17 | 753-06814 | Bracket, Lower |
| 18 | 753-04061 | Nut |
| 19 | 753-04062 | Cap |
| 20 | 753-04437 | Wheel (includes 19) |
| 21 | 791-182910 | Washer |
| 22 | 753-06815 | Spacer |
| 23 | 753-06816 | Axle |
| 24 | 753-06817 | Tube, Square |
| 25 | 753-06810 | Shield |
| 26 | 753-06812 | Tube (includes 27) |
| 27 | 753-04499 | Flex Shaft |
| 28 | 753-06811 | Clip |
| 29 | 753-05983 | Tine (Left Inner, Right Outer) |
| 30 | 753-05984 | Tine (Left Outer, Right Inner) |
| 31 | 791-182195 | Screw |
| 32 | 791-180288 | Screw |
| 33 | 753-06063 | Gearbox (includes 31) |
| 34 | 753-04057 | Cotter Pin |
| 35 | 753-06969 | Clevis Pin |