




Equipment Sizing Guide



Use the map above to determine your region and compare to the chart below to find your application size.

Residential A/C System Sizing

Square Footage	Region 1	Region 2	Region 3	Region 4	Region 5	Condenser Size
	940-1300	880-1235	835-1165	680-955	680-955	1.5 TON
	1300-1680	1235-1580	1165-1500	955-1225	955-1225	2.0 TON
	1680-2060	1580-1940	1500-1830	1225-1500	1225-1500	2.5 TON
	2060-2435	1940-2290	1830-2165	1500-1770	1500-1770	3.0 TON
	2435-2810	2290-2645	2165-2500	1770-2045	1770-2045	3.5 TON
	2810-3375	2645-3175	2500-3000	2045-2455	2045-2455	4.0 TON
	3375-3935	3175-3705	3000-3500	2455-2860	2455-2860	5.0 TON

Residential Sizing: The table and charts are intended to be used as a guideline for Residential applications only. The information is based on conventional window space (<15%), insulation and building construction (8 ft. ceiling height). When including a finished basement, use 1/2 of the finished basement square footage with the rest of the area being calculated.

Mobile/Manufactured Home Sizing: Refer to the Date Plate located in the electrical box or kitchen cabinets. For further assistance, call Hamilton's customer service department (800) 879-0123.