


USE AND CARE GUIDE

Alveranda Dining Table (68 IN. X 38 IN. Dining Table)



Questions, problems, missing parts? Before returning to the store, call Hampton Bay Customer Service
8:00 a.m. - 7:00 p.m., EST, Monday-Friday
9:00 a.m. - 6:00 p.m., EST, Saturday

1-855-HD-HAMPTON

HAMPTONBAY.COM

THANK YOU

Table of Contents

Table of Contents	2
Safety Information	2
Warranty	2
5 Year Frame Limited Warranty	
2 Year Table Top Limited Warranty	
What Is Covered?	2
What Is Not Covered?	2
Care Instructions	2

Pre-Assembly	3-4
Planning Assembly	
Hardware Included	
Package Contents	4
Assembly	5

Safety Information



DANGER: Please keep children out of the assembly area before assembly.



WARNING: Do not sit or stand on the table.



WARNING: Do not put heavy objects on the table.



CAUTION: Use the table on flat ground only.



IMPORTANT: Please check the tightness of the bolts at least every 90 days.



NOTE: Level the table with glides at the bottom of each

Warranty

5 YEAR FRAME 2 YEAR TABLE TOP LIMITED WARRANTY

WHAT IS COVERED

We warrant the frame to be free of manufacturing defects to the original purchaser for five years and the table top for 2 years.

WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center. This warranty does not cover commercial use, hardware, acts of nature, fire, freezing and abusive use. In addition, purchased parts are not covered under this warranty. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

Care Instructions

Before using, wipe with a clean, dry cloth. Do not use bleach or solvents. Treat the frame with liquid wax for maximum protection against UV light and salty, damp air. When not in use, store furniture in a cool, dry place. If the set includes cushions or mesh fabric, they may be cleaned by hand with a mild solution of soap and water. Rinse cushions thoroughly and allow to drip dry. Do not machine wash or tumble dry, as cushions may shrink. Do not use bleach or solvents on fabrics. When cleaning the tabletop make sure to use a soft, clean cloth that does not bleed color.

You may contact our customer service department with any questions by phone at 1-855-HD-HAMPTON or visit www.hamptonbay.com.

Pre-Assembly

PLANNING ASSEMBLY

Assemble this product on a blanket, towel or other soft, non-abrasive surface to avoid scratching the finish.

HARDWARE INCLUDED



NOTE: Hardware not shown to actual size.










Description	Quantity
Bolt (M6 x 20 mm)	16
Metal Washer (M6)	16
Plastic Bolt Cap (M6)	16
Hex Wrench (M6)	1
	Bolt (M6 x 20 mm) Metal Washer (M6) Plastic Bolt Cap (M6)

Pre-Assembly (continued)

PACKAGE CONTENTS








Part	Description	Quantity
Α	Ceramic Tile	4
В	Table Top Frame	1
С	Table Leg	4

Assembly

Attaching the table legs to the table top frame


- □ Place the table top frame (B) upside down on a blanket, towel, or other soft surface so the pre-drilled corner holes are visible.
- ☐ Attach the four table legs (C) to the table top frame (B) by inserting the bolts (AA) with metal washers (BB) through the pre-drilled holes.
- □ Tighten all the bolts using the wrench (DD) and cover all bolts with bolt caps (CC).



Placing the ceramic tile

☐ Turn the table in the upright position and carefully place the ceramic tiles in place on the table top.

Your table is now ready for use, so relax & enjoy!





Questions, problems, missing parts? Before returning to the store, call Hampton Bay Customer Service
8:00 a.m. - 7:00 p.m., EST, Monday-Friday
9:00 a.m. - 6:00 p.m., EST, Saturday

1-855-HD-HAMPTON

HAMPTONBAY.COM

Retain this manual for future use.