



Cottage Arbor

Model# 11162 (M) Assembly Instructions

Part #	Description	Box#	Qty
1	2" sq. x 65" Left Post	1	1
2	2" sq. x 65" Right Post	1	1
3	7/8 x 1 1/2 x 27 1/2" Top/Bottom Cross Rail	1	2
4	7/8 x 1 1/2 x 27 1/2" Center Cross Rail	1	5
5	1 x 1 x 58" Vertical Rail	2	3
6	2" sq. x 50" Arbor Top	2	2
7	1 x 1 x 27 1/2" Arbor Top Cross Rail	2	8
8	Hardware Bag (includes:)	2	1
	1 1/4" Painted Screw		8
	3/4" Painted Screw		12
9	Arbor Ground Anchor Kit (includes:)	2	1
	16" Steel Ground Anchor (L-Shaped)		4
	#8 - 1" Painted Self Tapping Screw		8

General Information

PLEASE READ THROUGH BEFORE BEGINNING ASSEMBLY.

IMPORTANT: Check boxes for Contents Listed

Check inside of parts as some parts are packaged inside of others

In the event of missing, damaged or defective parts please call our customer service dept. at 1-877-258-6020

When assembling components, place on a clean, flat non-abrasive surface to avoid scratches

Tools Required

- ... Battery or Electric Drill with #2 phillips bit
- ... Tape Measure
- ... Hammer or Rubber Mallet (recommended)