General Use and Care

Use

Always be sure to choose the proper tool for the job at hand. Improper use could lead to injury.

Before using a hammer inspect to ensure it is in good condition. Do not use if rounded, mushroomed, or damaged head and/or loose/damaged handle.

Discard, repair or replace any tool that shows visible damage.

Do not strike nails or other objects with the cheek of the hammer..

Never strike one hammer against another hammer.

Do not use a hammer if your hands are oily, greasy or wet.

Cleaning

Always clean your tools immediately after use.

Spray light oil on areas prone to rust.

Storage

Store tools in a clean and dry environment.

Maintenance

Keep metal blades sharp and well-oiled.

Check any screws, blades and handles regularly for wear or damage, and replace if necessary.

ALWAYS WEAR SAFETY GOGGLES USER AND BY-STANDERS.

