

# Features

## Start

## Notice:

The spray gun you have purchased will have some or all of the features and accessories shown here. Refer to the graphic, right, and the chart, below.

### Features

Features	Power Painter Plus	Power Painter Max	Power Painter Pro
<b>a</b> Adjustable spray tip assembly	✓	✓	✓
<b>a1</b> Tip nut	✓	✓	✓
<b>a2</b> Spray adjustment guard	✓	✓	✓
<b>b</b> 1 quart cup			
<b>c</b> 1 1/2 quart cup		✓	✓
<b>d</b> Cup release button	✓	✓	✓
<b>e</b> Cup grip			
<b>f</b> Cup handle		✓	✓
<b>g</b> Trigger	✓	✓	✓
<b>h</b> Material select lever	✓	✓	✓
<b>i</b> Electronic material selector			✓
<b>j</b> Electronic speed control		✓	✓
<b>k</b> Low cup level indicator		✓	✓
<b>l</b> Remote suction hose kit		✓	✓
<b>m</b> Fill lid adapter (for threaded containers)		✓	✓
<b>n</b> Fill lid (standard containers)	✓	✓	✓
<b>o</b> Cleaning brushes, cleaner nozzle and lubricant	✓	✓	✓
<b>p</b> Backpack kit			✓

