



VINYL ROLLER SHADE SHORTENING INSTRUCTIONS

Locate the end of the shade that has a round pin (A). (Fig. 1)
 Place a small mark on the hem of the shade (B) to indicate your desired width. (Fig. 2)
 Use scissors to make a small cut through the shade hem at your mark. (Fig. 3)
 Gently tear the shade starting where you made the cut through the hem. Telescope the shade as in diagram Fig. 4 and continue tearing to the cardboard roller. Remove excess shade material.
 Tear off excess cardboard and push the end of the roller inward to match the new width of the shade. (Fig 6)
 Snap off the slat to match the width of the shade and insert the slat into the shade hem. (Fig. 6)
NOTE: If you prefer, you can also cut your shade to your desired width with a scissors. Follow steps 1 and 2 above, then unroll the shade and use a scissors to cut the entire length of the vinyl starting at your mark. Continue with step 5.

ROLLER SHADE INSTALLATION INSTRUCTIONS

MOUNT BRACKETS
Inside Mount (Fig. 7):
 Mount brackets 1/4" from the top of the window sill to allow large diameter shades to fit into brackets easily. The bracket with the circular hole insert (A) should be mounted on the right and the bracket with the cutout (B) should be mounted on the left.
Outside Mount (Fig. 8):
 Measure blind from tip to tip. The brackets should be mounted no more than the measured distance and no less than the measured distance minus 1/4" (the measurement is made from the back of each bracket). The right bracket will have the circular hole insert (A) and the left bracket will have the cutout (B).
Universal Brackets (Fig. 9):
 For an inside mount refer to figure 9, but use inside mount instructions above.
 For outside mount refer to figure 9, but use outside mount instructions above.

MOUNT SHADE
 Insert round pin of shade into circular hole of bracket (A). Insert flat pin into cutout of bracket (B).

TO ADJUST SHADE ROLLER TENSION
 Roll shade up and hang in brackets. If there is not enough strength in the spring to raise shade completely, pull shade down to about half the window opening. Remove shade from brackets, roll up by hand, and then place back in brackets. Should spring be too strong, raise shade to top of window, remove from brackets and unroll several turns by hand, then replace in brackets.

PERSIANA ENROLLABLE DE VINILO INSTRUCTIONS

Ubique el extremo de la persiana que tiene un gancho redondo (A). (Fig. 1)
 Ponga una marca pequena en el borde de la persiana (B) para indicar el ancho. (Fig. 2)
 Haga un pequeno cone con las traves del borde de la persiana en la marca. (Fig. 1)
 Corte con mucho cuidado la persiana comenzando en el lugar donde hizo el corte a traves del borde. Extienda plegacia la persiana como se muestra en el diagrama Fig. 4 y siga cortando hasta el rodillo de cartulina. Romueva el sobrante de material de la persiana.
 Corte la cartulina sobrante y empuje el extremo del rodillo hacia adentro para que calce con el nuevo ancho que tiene la persiana. (Fig. 5)
 Abra hacia fuera la tabilla para que calce con el ancho de la persiana y despues inserte la tabilla en el borde de la persiana. (Fig. 6)
NOTA: Si usted prefiere, puede cortar tambien la persiana con las tijeras at ancho de su preferencia. Siga los pasos 1 y 2 de arriba, enseguida enrolle la persiana y corte con las tijeras todo el largo del vinilo comenzando en la marca. Siga con el paso 5.

INSTRUCCION PARA INSTALAR LA PERSIANA DE RODILLO

(No se incluyen mensulas)
INSTALACION DE LAS MENSULAS
Instalacion Interna (Fig. 7):
 Instale las mensulas 6.35mm desde la parte de arriba del marco de la ventana para que las persianas de mayor diametro calcen facilmente en las mensulas. La mensula con el agujero de insercion circular (A) debe instalarse a la derecha y la mensula con el corte (B) debe instalarse a la izquierda.
Instalacion Externa (Fig. 8):
 Mida la persiana de extremo a extremo. Las mensulas deben instalarse a una distancia no mayor que la distancia medida y no menor que esa distancia menos 6.35mm (la medida se toma desde la parte de atras de cada mensula). La mensula derecha lendra el agujero de insercion circular (A) y la mensula izquierda tendra el corte (B).
Soporte Universal (Fig. 9):
 Para instalar dentro del marco de ventana referase a la figura 9 pero use las instrucciones arriba para den dentro del marco. Para instalar fuera del marco de ventana referase a la figura 9, pero use las instrucciones arriba par fuera del marco.

INSTALACION DE LA PERSIANA
 Inserte el gancho redondo de la persiana en el agujero la mensula(A). Inserte el gancho pano en la mensula con corte (B).

PARA AJUSTAR LA TENSION DE LOS ENROLLABLES
 Enrolle la persiana hacia arriba y coloque los soportes. Si no hay suficiente fuerza en el resorte para subir la persiana completamente. lire la persiana hacia abajo mas o menos hasta la mitad de la ventana. Quite la persiana de los soportes y enrollela a mano y coloquela en los soportes. Si el resorte fuese muy fuerte suba la persiana hasta arriba de la ventana, quitela de los soportes y desenlielle varios turnos a mano, despues coldquela en los soportes.