

# **12" FLOOR FAN**



Model: ILG8F12

**Owner's Manual** 

## PLEASE READ AND



SAVE THESE INSTRUCTIONS

### **INTENDED USE**

This product is intended only for indoor residential and office use, not for industrial or other commercial use. Use your fan only with adequate wiring that matches Code. If you have any questions about the adequacy of your wiring, consult a qualified electrician. As with any electrical appliance use only with a smoke detector that is in proper working order. In using your fan, you should read and follow the IMPORTANT INSTRUCTIONS below. The word WARNING in these instructions indicates a hazard that, if not avoided, could result in injury or death.

**IMPORTANT INSTRUCTIONS** When using or servicing electrical appliances, basic safety precautions should always be followed to reduce the risk of electric shock, and injury to persons, including the following: Use this fan only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons. Do not place fan on an uneven or surface smaller than fan which might allow fan to tip or fall causing damage to property or injury to people. Do not use in a window. Extreme caution is necessary when fan is used by or near children or people with physical challenges. Do not use the fan with the fan guards removed. Do not sit or stand on fan. Do not place objects on fan.

To reduce the risk of fire or electric shock, do not use this fan with any solid state speed control device such as a dimmer switch. Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause electric shock, and/or a fire hazard. Do not use it in areas where gasoline, paint, or flammable materials are used or stored. A fan has sparking parts inside. Do not leave fan where drapes or curtains will get pulled into the fan or against the fan guard.

This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. DO NOT attempt to defeat this safety feature. Do not operate any fan with a damaged cord or plug or after the fan malfunctions, has been dropped or damaged in any manner. Do not route cord under carpeting or cover cord with throw rugs, runner, or the like. Arrange cord away from traffic area and where cord will not be tripped over. Use your fan only in dry environments. Do not place fan in bathroom, laundry area, or similar locations, or near sinks, washing machines, swimming pools or other sources of water.

**WARNING**: "THIS IS A FAN—NOT A TOY!" TO REDUCE THE RISK OF PERSONAL INJURY AND ELECTRIC SHOCK, IT SHOULD NOT BE PLAYED WITH OR PLACED WHERE SMALL CHILDREN CAN REACH IT

#### HOW TO USE

Plug fan directly into 120 volt AC wall outlet. Be sure plug fits tightly in outlet. A loose fit will cause overheating and damage to the plug. Always operate fan on its base in the normal upright position.

Set the selector switch to the desired position.

To disconnect fan; turn switch off, then remove plug from outlet.

### CARE AND CLEANING

BEFORE CLEANING THE FAN UNPLUG THE POWER CORD. Remove front grille by removing screws. (Do not remove rear grille) Clean grilles and blade with damp cloth. Avoid harsh chemical cleaners. DO NOT IMMERSE THE MOTOR IN WATER. Re-attach front grille. Allow fan to dry completely before use. Excess dust accumulated on the vent slots of the motor can be easily removed with a vacuum cleaner. Your fan motor is permanently lubricated and requires no additional oil.

#### Product Specifications Model#: ILG8F12

Voltage: 120V, 60Hz Current: 0.56 amps; Power: 49 Watts iLIVING USA 239 Harbor Way South San Francisco, CA 94080 Tel: 800-317-1688 Email: service@ilivingusa.com