

Evolut Use and Care Manual

- Be careful when wearing sharp clothing articles like belt buckles and zippers. They will damage your furniture. Be especially cautious when leaning over the crib or dresser.
- Dust your furniture at least once a week with a lint-free cloth dampened with polish or cleaner. Polish it every four months.
- Don't expose your furniture to strong sunlight or extreme changes in temperature or moisture. This can damage or fade its color.
- Do not place your furniture in front of or over heating or air conditioning vents.
- Take care when placing plastic materials (placemats/ lamp bases/ notebooks/etc.) directly on your furniture. Certain plastics have ingredients that may react with and damage the finish.
- When using a vinyl changing pad place a protective cloth over your furniture to keep from scratching and damaging the finish. Do not place changing pad belts under the pads as these can also scratch the finish.
- Use a felt mat (not plastic) to protect your furniture.
- Wipe up spills promptly. Water left too long on your furniture will leave white spots on the finish. Urine can cause discoloration. Alcohol/ perfume/ aftershave and medicines can cause severe and permanent damage.
- Be very careful when using a vaporizer. Moisture is not good for the finish. Make sure the vapor stream is always aimed away from the furniture.
- Do not drag objects across the top surface of your furniture. Always lift them to avoid scratching the finish.
- Avoid placing mobile devices accessories or any item that clamps on to furniture/crib as they can cause scratching and other forms of damage to the finish of the crib/furniture.