


OWNER'S MANUAL

**9" WINDOW FAN  
MODEL: WFT9**



**SOME ASSEMBLY REQUIRED**

Call Toll Free: 1-866-876-4332

**READ AND SAVE THESE INSTRUCTIONS**

## CAUTION

Read Rules for Safe Operation and Instructions Carefully.

## WARNING

1. To reduce the risk of fire or electric shock, do not use this fan with any solid-state speed control device.
2. This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit in a polarized outlet only one way. If plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.
3. Do not leave the fan running unattended.
4. Please make sure the voltage of the power supply is the same as shown on the fan nameplate.

## RULES FOR SAFE OPERATION


When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock and injury to persons, including the following:

1. The rules about cord and plug as below:
  - (1) This product employs overload protection (fuse). A blown fuse indicates an overload or short-circuit situation. If the fuse blows, unplug the product from the outlet. Replace the fuse as per the user servicing instructions (follow product marking for proper fuse rating) and check the products. If the replacement fuse blows, a short-circuit may be present and the product should be discarded or returned to an authorized service facility for examination and/or repair.
  - (2) Do not operate any fan with a damaged cord or plug. Discard fan or return to an authorized service facility for examination and/or repair.
  - (3) Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Do not route cord under furniture or appliances. Arrange cord away from traffic area and where it will not be tripped over.
2. Never insert fingers, pencils, or any other object through the grille when fan is running.
3. Disconnect fan when moving from one location to another, before putting on or taking off parts.
4. Disconnect fan when removing grilles for cleaning.
5. Do not operate in the presence of explosive and/or flammable fumes.
6. Do not place fan or any parts near an open flame, cooking or other heating appliance.
7. Always use on a dry, level surface, do not use outdoors.
8. Do not let the cord hang over the edge of a table, counter, or come in contact with hot surfaces.
9. To disconnect grip plug and pull from wall outlet. Never yank on cord.

## INSTALLATION INSTRUCTION

This window fan comes fully assembled and is ready for immediate installation.



This window fan has been designed to fit double-hung, slider and casement windows with minimum openings of 24" Wide and 13" high. This fan is designed and recommended for used with your window screen in place.



1 Left Fan Speed Control  
2 Fan Intake-Exhaust/Air Exchange  
3 Thermostat Control  
4 Right Fan Speed Control  
5 Extender Locks


## OPERATING INSTRUCTIONS

1. Make sure rotary switches are in the OFF position.
2. Plug into 120V AC electric outlet.
3. Set the individual fan motors on either IN, OUT or EXCH using the control lever.
4. Turn the Thermostat Control to its highest setting (fully clockwise).
5. To start the unit turn the rotary switches to desired speed.
6. While the window fan is on, turn the Thermostat Control counter-clockwise towards the smaller dots until the fan stops (Away from Cooler). This is the selected comfort level.
7. If the fan is stopped and you want to turn it back on, turn the Thermostat Control clockwise until the fan starts, towards the larger dots (Towards Cooler).



## USER SERVICING INSTRUCTIONS

1. Grasp plug and remove from the receptacle or other outlet device. Do not unplug by pulling on cord.
  2. Open fuse cover. Slide open fuse access cover on top of attachment plug towards blades.
  3. Remove fuse carefully. Push the fuse from the other side or turn fuseholder over to remove fuse.
  4. Risk of fire. Replace fuse only with 2.5 Amp, 125 Volt fuse (provided with product.)
  5. Close fuse cover. Slide closed the fuse access cover on top of attachment plug.
  6. Risk of fire. Do not replace attachment plug. Contains a safety device (fuse) that should not be removed. Discard product if the attachment plug is damaged.
- Notice: 1. When you replace fuse, please don't operate suddenly or overexert, or else the product will be damaged or cause accident.  
2. When you feel it hard to be operated, please make sure you have got the right way.



## MAINTENANCE INSTRUCTION

The fan requires little maintenance. Do not try to fix it by yourself. Refer it to qualified service personnel if service is needed.

1. Before cleaning and assembling, do not plug the pins into the socket.
2. To ensure adequate air circulation to the motor. Keep vents at the rear of the motor housing from dust, fluff and etc. A vacuum cleaner can not be used to clean these vents before unplug. Do not disassemble the fan remove fluff.
3. Please wipe the exterior parts with a soft cloth soaking a mild detergent.  
Do not use any abrasive detergent or solvents to avoid scratching the surface.  
Do not use of the following as a cleaner: gasoline, thinner, benzene.
4. Do not allow water or any other liquid into the motor housing or interior parts.

## CLEANING

1. Be sure to unplug the power cord from the outlet before cleaning.
2. Plastic parts should be cleaned with mild soap and damp cloth or sponge.  
Thoroughly remove soap film with clean water.
3. Be sure not to get water or other liquid enter the inside of the motor.
4. Dry all parts completely before reassembling and reconnecting to power source.

PRINTED IN CHINA

## SPECIFICATIONS

Model No.: WFT9

Voltage: 120V, 60Hz

## SERVICE & SUPPORT

In the event of a warranty claim or if service is required for this fan, please contact us at the following:

Toll Free: 866-876-4332 (M-F 9:00am to 5:00pm CST)

For questions or comments, please write to:

Midea USA, INC.

Att: Warranty Department

1937 N Great Southwest Parkway

Grand Prairie, TX 75050, USA

For your records, staple your sales receipt to this manual and record the following:

**DATE OF PURCHASE:** \_\_\_\_\_

**PLACE OF PURCHASE:** \_\_\_\_\_

**(STAPLE SALES RECEIPT HERE)**

**NOTE: PROOF OF PURCHASE IS REQUIRED FOR  
ALL WARRANTY CLAIMS**

## **ONE(1) YEAR LIMITED WARRANTY**

- Please read all instructions before attempting to use this product.
- Please return the Warranty Registration card within fifteen (15) days from the date of purchasing this product.

Midea USA, INC., referred to hereafter as Midea USA, warrants as limited herein to the original purchaser of retail that each new WFT9 9" Window Fan, shall be free of defects in material and workmanship for a period of one (1) year from the date of original purchase. This one (1) year warranty is limited to the fan motor, fan blades, and electric control circuit board.

In the event of malfunctions or failure of your WFT9 9" Window Fan, simply deliver or send the product, postage prepaid along with PROOF OF PURCHASE, within the warranty period of one (1) year, to Midea USA. Midea USA reserves the right to inspect the claimed defective part or parts to determine if the defect or malfunction complaint is covered by this warranty. Midea USA shall, within sixty (60) days after receipt of the product, at its option, repair and/or replace the defective part or parts free of charge. This warranty shall only cover defects arising from normal usage.

Midea USA assumes no responsibility whatsoever if the WFT9 9" Window Fan should fail during the warranty period by reasons of:

- Misuse, negligence, physical damage or accidents.
- Lack of maintenance (see cleaning).
- Repair by any unauthorized party during the warranty period.
- Damage caused by connection to an improper input voltage (see specifications).

Midea USA makes no further warranties or representations, express or implied except those contained herein. No representative or dealer is authorized to assume any other liability regarding the WFT9 9" Window Fan. The duration of the implied warranty granted under State law, including warranties of merchantability and fitness for particular purpose are limited in duration should the duration of the express warranty grant it hereunder. Midea USA shall in no event be liable for direct, indirect, special or consequential damages.

Some states do not allow limitations on how long an implied warranty lasts, and/or the above limitations or exclusion may not apply to you. This warranty gives you specific legal rights and you may have other rights, which vary from state to state.

Should your WFT9 9" Window Fan fail to operate under the terms of this limited warranty, contact Midea USA at 866-876-4332 (M-F 9:00am to 5:00pm CST).