

## **ASSEMBLY INSTRUCTIONS (FIRE GLASS)**



Fire glass should be placed in the fireplace, or fire pit to a depth of 1” to 2”. Be sure to keep fire glass clear from your igniter to be sure it doesn’t interfere with the functionality of the igniter. See our Care and Use Manual for care and cleaning instructions.