














Assembly Instructions

List parts of Club Chair


No	Picture	Parts	Qty	No	Picture	Parts	Qty
A		Chair Back	1	G		Bolt Dia.M6*35mm(L)	4
B		Left Arm	1	H		Bolt Dia.M6*40mm(L)	8
C		Right Arm	1	I		Flat washer Ø16*1.2mm(TH)	12
D		Chair Seat	1	J		Spring washer Ø16*2mm(TH)	12
E		Leveler	4	K		Allen key	1
F		Plastic cap (to cover bolt heads)	12				




Assembly Instructions:




Step 1 and 2 : Open the carton and place all the parts onto a clean and soft surface,compare the real parts with the above list to make sure each part is available,place the left arm (B) with its inside facing up onto the soft surface,put the chair back(A)against the left arm(B) with the chair back(A)'s upper metal rod inserted into the top rear end of left arm(B), attach them together with flat washer(I)+spring washer(J)+bolt(H),use an Allen key(K) to tighten them, but not completely.



Step 3 and 4 : Place the chair seat (D)with its short side facing front between the left arm(B) and chair back(A),attach the chair seat(D)to the left arm(B) on their sides with flat washer(I)+spring washer(J)+bolt(G), attach the chair seat(D) to the chair back(A) on the rear side with flat washer(I)+spring washer(J)+bolt(H),use an Allen key(K) to tighten them ,but not completely



Step 5,6 and 7 : Place the right arm (C) against the chair back(A) and chair seat(D), insert the chair back(A)'s upper metal rod into the top rear end of right arm(C),attach the chair seat(D) to the right arm(C) with flat washer(I)+spring washer(J)+bolt(G),attach the chair back (A) to the righ arm(C) with flat washer((I) + spring washer(J)+bolt(H), use an Allen key(K) to tighten them ,but not completely



Step 8 and 9 : Turn the leveler(E)into the chair body,tighten all bolts completely and put the plastic cap(F)to cover the bolt heads, adjust the leveler(E)to ensure good stability, it is ready for use.

Care & Maintenance



- Do not put **HOT** items directly on furniture surface.



- Do not clean furniture with **HARSH** cleansers or polish.



- To prolong product lifetime, **AVOID** placing furniture under direct sunlight.



- Do not place furniture near **heating or cooling** vents.



- Do not write on furniture without a padded barrier to protect the surface.



- To prolong the product lifetime, avoid extended and lengthy exposure to rain and sunshine. Where possible, place under covers and or patio and or awnings.



- For residential use only. Not for commercial use.



- Stains may be removed with mild soap solution and damp cloth.



- Dust and pick-up spills using a clean, non-colored, lint-free cloth.