

Cleaning instructions for mailboxes, drop boxes, parcel box

The maintenance frequency depends on where you live and how well your product is protected from the sun and weather. Products in harsher environments require more frequent care. As a general guideline, if your product begins to look dirty or weathered, it's time to clean it. Using a soft cloth or sponge, clean the interior and exterior of the mailbox/dropbox with liquid soap, detergent, or diluted water-soluble household cleaners. Completely remove residue of any cleaning products with water and thoroughly dry with a clean cloth or paper towel.