

customerservice@firepitessentials.com (877) 447-9797

COVERAGE CALCULATOR

Calculator for Square or Rectangle Fire Pit:

Width X Length X Depth, divided by 19 = pounds of fire glass needed. We recommend a minimum 2" of fire glass depth for most installations. For example, a 20" X 25" fire pit at the recommended 2" of fire glass depth: 20 X 25 X 2, divided by 19 = 52 lbs.

Calculator for Circular or Rounded Fire Pit:

Diameter X Diameter X Depth, divided by 24 = pounds of fire glass needed. We recommend a minimum 2" of fire glass depth for most installations. For example, a 25" diameter fire pit at the recommended 2" of fire glass depth: 25 X 25 X 2, divided by 24 = 52 lbs.

USE AND CARE RECOMMENDATIONS

Decorative glass pieces are heat-resistant when used with standard gas fireplaces and under non-extreme heat conditions. Wet glass should never be placed on a fire; allow them to dry completely before burning. Though rare, wet glass could crack or pop out when they become hot. After several burns, the glass may develop a residue or discoloration from charring. Wash with lukewarm water and soap to remove these stains.

PRODUCT WARRANTY

The Fire Pit Essentials products are fully warranted to the original owner against defects in materials and workmanship for the lifetime of the product. If a product ever fails due to a manufacturing defect, even after extended use, we will replace the product, without charge. This warranty does not cover damage caused by accident, improper care, negligence, normal wear and tear, or the natural breakdown of colors and materials over extended time and use. Damage to product not covered under warranty will be replaced for a reasonable rate and a fee will be charged for return shipping.



CAUTION: Fire glass can be sharp and should be handled with caution. It is recommended to wear gloves and safety glasses while handling product.