
Assembly Instructions


Wooden Sun Lounger



Caution : Do Not Swing on or in hammock. This could cause the product to tip over resulting in possible injury.


resulting in possible injury.					
Parts List					
Label	Picture	Description	QTY		
L		Canopy Supporting Bar	1		
М	<u>(iii iii)</u>	Bed Bar	2		
Ν		Bottom Supporting Bar	2		
0		Canopy Side Supporting Bar	2		
Р		Leg	4		
Q		Canopy End Bar	2		
R	The second se	Canopy Arch Bar	2		
Ι		Outdoor Mesh Bed Fabric	1		
V		Canopy	1		
W		Pillow	2		

Hardware				
Label	Picture	Description	QTY	
А		Bolt(M10×130MM)	8	
В		Bolt(M8×90MM)	18	
С	()	Bolt(M6×45MM)	4	
D		Tubular Nut	16	
Е		Nut	8	
F	0	Washer	16	
G		Handle	2	
Н		Wrench	2	
J		Allen Key	2	
К		Allen Key	1	
S		Bolt(M6×65MM)	2	
Т		Bolt(M8×110MM)	4	
U		Nut	6	
Assembly Preparation				
Before Beginning Assembly:				




- Have 2 adults on hand for assembly-
- Do not assemble on flooring or carpet-
- Assemble on a clean non-marring surface (packing foam)-
- Save all packaging until finished-


Assembly Steps




This Lounger has multiple parts and may require up to 90 minutes to assemble. To give you an overview of the Lounger parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.

NOTE: 2 OR 3 PEOPLE ARE RECOMMENDED TO ASSEMBLE THIS Lounger.







Са	re &Maintenance			
0	Do not put hot items directly on furniture surface			
0	 Do not clean furniture with harsh cleansers or polish. 			
~	To obtain the longest lifespan of your outdoor prodcts, minimizing exposure to direct sunlight is recommended.			
0	 Children should not climb or jump on the furniture. 			
0	 Do not write on furniture without a padded barrier to protect the surface. 			
~	To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.			
0	Not for commercial use. For residential use only .			
0	 Stains may be removed with mild soap solution and damp cloth. 			
oposi 0-plu	Dust and pick-up spills using a clean, non-colored, lint-free cloth . Proposition 65? tion 65 is a California law that requires warning labels on products that may contain one of more than s chemicals or ingredients that the California Office of Environmental Health Hazard Assessment			
lude	A) has deemed to cause cancer or other reproductive toxicity. Chemicals and elements on this list wood dust, brass, and other everyday substances, which can be found in very common household such as: lamps, tableware, jewelry, crystal glasses, electric cords, beauty products, automobiles, and e.			
ny Die	d I Find a Proposition 65 Warning on My Home Goods Product?			
0-plu cking	ude Proposition 65 warnings on all of our products because there is always a chance that one of the s common chemicals and ingredients listed under this law could potentially be on our furniture or materials. We risk large fines under this law, if we don't include this warning.			
e real zardo ipped ece of st Ho	I worry? lize you may be worried finding this warning on our products, but we want to reassure you that the bus exposure limits for any of these chemicals have never been found on furniture products that we've I to our customers. Additionally, this warning label is very common and can be found on almost every f furniture sold in the state of California. I we Common Are Proposition 65 Warnings?			
ocery	ition 65 warnings have become so common in California that it is hard to take a trip to a local bank, store, or restaurant without finding at least one warning. In fact, even the Disney Land Resort has a ition 65 warning:			
	WARNING: The Disneyland Resort contains chemicals known to the state of California to cause cancer and birth defects or other reproductive harm. Proposition 65, California Health & Safety Code Section 25249.6 et seq.			