



Use and Care

1. Keep blade free of debris. Clean the blade with a dry cloth after each day pruning.
2. Sharpen the blade when cutting needs more effort.

For safety reasons always keep knife closed when not in use.