



Freenotes Harmony Park Maintenance

Maintenance for these instruments is easy, they are virtually maintenance free.

The instrument(s) need to be inspected once per month to once per quarter, based on use.

The inspector should:

- 1 – Play the instrument(s).
- 2 – Clean the instrument(s) with soap and water if necessary. Remove any trash or debris.
- 3 – Check that the mallets are attached and in good shape
- 4 - Inspect all bar and chime attachment cables

To clean stubborn dirt or marks on aluminum chimes or keys use - **Goof Off – Heavy Duty Remover**

If the inspector finds a problem please contact Freenotes Harmony Park at (970) 375-7825 or your Freenotes distributor. We can provide re-lacing kits, replacement mallets with cables, and our expertise for any issue.