



Caring For Your Vanity Top

All KraftMaid® Vanity Tops

- Use coasters under glasses or other objects that may scratch your vanity top surface.
- Use mild soap and water routinely.
- Clean up spills of acidic liquids such as fruit juices or vinegar immediately.
- Avoid exposing your KraftMaid® Countertop to strong chemicals, scouring-type cleaners, paint removers, rust removers and oven cleaners.
- Don't use bleach or vinegar on your vanity top.
- Don't use wax or finishes requiring high-speed polishing.
- Don't place hot items such as pots, pans, plates or curling irons on your vanity top. Always use a hot pad or trivet under hot pots and heat-producing appliances.
- Don't score or cut directly on the vanity top. Always use a cutting board.
- Don't stand on your vanity top.

Natural Quartz

- Clean natural quartz surface regularly using mild soap, water and soft cloth.
- Don't use wax, sealers, window cleaning solution or other topical finishes.
- Don't use Scotch-Brite® pads on your vanity top because they will dull the surface.

Solid Surface

- Don't use wax, sealers, window cleaning solution or other topical finishes.
- Scotch-Brite® pads can remove small scratches on the vanity top. Consult with a KraftMaid® Countertop expert or the manufacturer of Scotch-Brite® for more information.
- Run cold water when pouring boiling water into your sink.
- Remove nail polish spills with an acetone-free polish remover and then flush the area with water.

Natural Stone

- Clean surfaces regularly with mild soap and water
- Your vanity top was sealed at the time of fabrication but may need to be resealed in the future. To test if sealing is required, splash a couple of drops of water on the surface. If the water is quickly absorbed into the stone, it is time to reseal your vanity top. If it takes 15-30 minutes to be absorbed or evaporated, you do not need to reseal your top.
- Don't use ammonia-based products or other general-purpose cleaners.
- Don't use Scotch-Brite® pads on your vanity top because they will dull the surface.

CUSTOMER CARE

888-562-3338 (USA) ▪ 877-214-1040 (CANADA)