

Gatsby Red (1104520) & Black (1

Description	PART #	
*KETTLE	110401	
DOOR (13 1/16" X 13 1/16")	514195	
DROP DOOR	514535	
CLEANOUT TRAY	514536	
*ELEMENT/KETTLE	514160	
*GEAR MOTOR	512096	
GLASS PANEL-FRONT	514370	
Size 14.38" X 17" X .125"		
Size 365mm X 432mm X 3.2mm		
EXTRUSION-FRONT-UPRIGHT-need 2 per glass	18169	
EXTRUSION-FRONT-BASE-need 1 per glass	18167	
GLASS PANEL-SIDE	514375	
Size 12.38" x 17" X .125"		
Size 314Mm X 432mm X 3.2mm		
EXTRUSION-SIDE-UPRIGHT-need 2 per glass	18169	
EXTRUSION-SIDE-BASE-need 1 per glass	18168	
HANGER-LEFT	512124	
HANGER-RIGHT	512128	
HINGE SET	512166	
KETTLE HANDLE ASSE.	512184	
SPRING ONLY FOR KETTLE HANDLE	12038	
KETTLE/LID HANDLE	512158	
KETTLE LID ASSE.	514040	
BULB (50 Watt Flood Light)	512161	
FEET W/RIVETS (4)	540322	
MAGNET	512100	
PIGTAIL	514101	
PIN&CLIP KETTLE HI	512188	
*POWER CORD	512092	
SOCKET LAMP	512155	
SOCKET KETTLE	514038	
STIRRER	514056	
*SWITCH SET (2)	514109	
THERMOSTAT	512139	
BLACK ENDCAPS (Set of 4)	512107	

*For us in Domestic (120v) models only

Export Parts (Part #1204510)

KETTLE	120401	
POWER CORD	512012	
GEAR MOTOR	512095	
KETTLE ELEMENT	514165	
SWITCH SET (2)	514100	