




# Service Parts

## MODEL TYPE



Part	Description	Part #
A	Top	1357FM-33-201-TOP
B	Outer Wall	PF-1357FM-33-201-OUTER WALL
C	Center Panel	INSERT-BOTTOM-MB
E	Left Front Panel	
F	Right Front Panel	
D	Base	PF-1357FM-33-201-BASE
H	Insert	3322-FG-BG
I	Remote Control	PU18-33CB-RC
K	Flip-Down Door Center Panels	PH-1357FM-33-201-CENTER PANELS

Part	Description	Part #
EE	KD Hardware Pack	PH-1357FM-33-201
FF	Flip-Down Door Hardware Set	PU17-1267FM-II/JJ/LL
GG	Flip-Down Door Handle	1357FM-33-HANDLE-WHT
HH	Leveler	T-1007
II	Insert Bracket	INSERT-STONE SIDE-MB