



## lavish home FLOOR LAMP

### Note:

Please read the Instruction sheet carefully before proceeding. Carefully unpack and identify all parts prior to building the unit. Each part is identified on the line drawing for reference. **DO NOT DISCARD THE ORIGINAL PACKAGING.** If after careful inspection you must return the item for any reason, please repack the unit using the original carton and inserts.

### IMPORTANT SAFETY INSTRUCTIONS

1. To reduce the risk of electric shock, this lamp has a polarized plug (one blade is wider than the other). The plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use an extension cord unless the plug can be fully inserted. Do not alter the plug.
2. To reduce the risk of fire, use the specified bulb type and do not exceed the specified lamp wattage identified on the product.
3. Turn off and unplug the unit to change bulbs. Allow the bulb to cool before touching.
4. Avoid laying objects directly over the power supply cord to avoid cutting or damaging the wire.


### BULB REPLACEMENT

Uses one 150 watt 3-way type A bulb or CFL or LED equivalent.

Includes regular LED Bulb. You will need to purchase a 3-way light bulb if you would like to avail of this lamp's 3-way lighting feature.

### Cleaning Instructions:

Do not use polish or cleaners. Wipe clean with a soft cloth.



### Assembly Instructions

1. Carefully pull out excess Power Cord from Base (F) while assembling to prevent the cord from becoming twisted.
2. Thread the Tube (E) onto the Base (F) until tight.
3. Repeat step 2 with tubes (D)(C) and (B).
4. Thread the socket assembly (A) clockwise onto the Tube (B) until tight.
5. Remove the Ring (H) from the Socket Cover.
6. Place the Glass shade (G) onto the Socket Assembly Cup (A). Tighten Ring (H) clockwise onto threaded socket cover to secure the Shade.