

Set up with the Nest app.



1

Open the Nest app.



2

Tap the gear icon.



3

Add the Nest
Temperature Sensor.

nest.com/setup/tempsensor
nest.com/support