

NEOPERL®

flow, stop and go®

Product Instructions


Description: 1.5 GPM Regular Female Faucet Aerator

Model#: 37.0085.98

SKU#: 705060

- 15/16"-27 Thread
- 1.5 gallon per minute
- Easy Installation

For male faucets with outside threads:



INSTRUCTIONS:

1. Remove old aerator from faucet. Use wrench if necessary.
2. Remove any old washers that might be caught inside the spout.
3. Clean the threads outside the faucet spout.
4. Install the new aerator onto the spout by hand.
5. Turn on faucet. If leak occurs, tighten more firmly.

INSTRUCCIONES:

1. Quite el viejo aireador del grifo. Utilice una llave inglesa de ser necesario.
2. Quite todas las arandelas viejas que pudieran haber quedado atrapadas dentro del surtidor de agua.
3. Limpie las roscas fuera del surtidor de agua del grifo.
4. Instale el nuevo aireador en el surtidor de agua en forma manual.
5. Abrir el grifo. Si ocurre un escape, ajuste más firmemente.

Visit us at www.neoperl.com/consumer and make changing your aerator part of your yearly faucet maintenance.