

Garden Winds

Customer Service

Phone: 877.479.4637

Email: customerservice@gardenwinds.com

User Care:

This replacement canopy has been designed for outdoor use. There is no maintenance required. We do recommend that you remove the canopy during off season non-use. This will help extend the life of the canopy.

If you need to clean the canopy, use a mild detergent and water solution. Gently use a sponge to clean the canopy. Then rinse off with water.