

# PURE GARDEN












PATIO AND GARDEN ESSENTIALS

Assembly Instruction – ITEM#50-154

26" SQUARE METAL FIRE PIT

Please check all packing material carefully before discarding, as some parts may be encased in the packing material.

**Part List:**

| Part List | Description        | Qty. | Drawings  |
|-----------|--------------------|------|---|
| A         | Top Frame          | 1    |    |
| B         | Leg                | 4    |    |
| C         | Frame Support Part | 4    |    |
| D         | Log Grate          | 1    |    |
| E         | Square Fire Bowl   | 1    |    |
| F         | Mesh Lid           | 1    |  |
| G         | Lid Ring           | 1    |  |
| H         | Bolt (M6x8)        | 20   |  |
| I         | Poker              | 1    |  |
| J         | Allen Wrench       | 1    |  |
| K         | PVC Cover          | 1    |  |

Tool required: Allen Wrench (provided)

## Special Warnings

- Check local bylaws before using the fire pit.
- This fire pit is intended for Outdoor Use Only! DO NOT use on wooden decks.
- This fire pit is intended to burn Wood Logs Only! DO NOT burn coal, leaves or other combustible materials in the fire pit.
- NOT for use by children. Keep children and pets away from the fire pit.
- Fire pit is hot, use with caution. NEVER touch hot fire pit with bare hands.
- NEVER leave burning fire pit unattended and always extinguish fire completely before leaving the fire pit.
- Maintain a minimum of 5 FT from any structure.
- DO NOT use near flammable or combustible objects or materials.
- Only CHROMED PLATED COOKING GRID is intended for cooking. LOG GRATE is NOT intended for cooking and SHOULD NOT be used for this purpose.

## Operation Instructions

- Place wood logs on grate and light with match. DO NOT overload logs.
- Please use Poker (provided) when handling.
- We do not recommend pouring water over the fire unless necessary. The fire should be allowed to expire on its own.

## Care and Maintenance


This fire pit is a quality-built product and is made to last for many years. The frame structure of this unit is made of powder-coated steel extrusion and should resist rusting under normal use. Should rusting occur, we suggest using a steel brush on the affected area followed by a spray coating of high temperature anti-rust paint. For additional rust proofing of the bowl, grate and mesh lid we recommend that a coat of high temperature primer (such as rustoleum or similar brand) is applied **before** use. You may cover the fire pit with a Protective Cover (provided) when the fire pit is not in use. Ensure the fire pit has completely cooled down before using the Protective Cover.

### WARNING!


- The use of alcohol, prescription or non-prescription drugs may impair the ability to properly assemble or safely operate this fire pit.
- When using this fire pit, exercise the same precautions you would with any open fire.
- Do not use this fire pit for indoor heating. Toxic carbon monoxide fumes can accumulate and cause asphyxiation or death.

**DO NOT** over tighten hardware

**Step 1)** Place parts on a smooth surface, attach Leg (B) to Top Frame (A) with Bolt (H). Tighten by hand and do not fully tighten all bolts.



**Step 2)** Attach Frame Support Parts (C) to Leg (B) by using Bolt (H). Tighten all hardware accordingly with an Allen Wrench (J) until all pieces fit together securely. Turn the assembled fire pit frame over so that it sits securely (legs down) on a flat surface.



**Step 3)** Place Fire Bowl (E) in the center of Top Frame (A) and put Log Grate (D) in the Fire bowl (E). Mount Lid Ring (G) on the Mesh Lid (F), then place the assembled Mesh Lid over the Fire bowl (E).

