

# Warranty

If this product fails due to a defect in material or workmanship within THREE YEARS from the date of purchase, we will at our option repair or replace it free of charge. This warranty excludes tires, wheels, brushes and bag, which are expendable and become worn during normal use.

**This warranty does not cover:**

- Repairs necessary because of operator abuse or negligence.
- Equipment used for commercial or rental purposes.
- Paint that is worn or faded due to normal use or exposure.

To arrange for product repair call 1-800-652-2321 to speak to our Customer Service Team, or return this product to place of purchase for replacement.

This warranty gives you specific legal rights, and you may also have other rights which may vary from state to state. This warranty applies only while this product is in use in the United States.

In the space below record the purchase date of your Lawn Sweeper.

Model Number **CC-4624V2** \_\_\_\_\_

Purchase Date \_\_\_\_\_

Retailer/Dealer \_\_\_\_\_

Purchase Price \_\_\_\_\_

Keep this Owner's Manual and your receipt in a safe place for future reference.

Replacement parts may be ordered by calling **1-800-652-2321** .

When ordering replacement parts, always give the following information:

- Product **24 cu ft LAWN SWEEPER** \_\_\_\_\_
- Model Number **CC-4624V2** \_\_\_\_\_
- Part Number \_\_\_\_\_
- Part Description \_\_\_\_\_