



# DELUXE BATTERY POWERED SIPHON PUMP

## OPERATING INSTRUCTIONS

1. INSERT BATTERIES AS SHOWN.



2. IMMERSE THE INTAKE (NON-FLEXIBLE) TUBE INTO THE SENDING CONTAINER.



3. INSERT DISCHARGE (FLEXIBLE) HOSE INTO THE RECEIVING CONTAINER OR FUEL TANK (HEATER)
4. TURN SWITCH ON - DO NOT LEAVE PUMP UNATTENDED DURING OPERATION - TURN SWITCH OFF BEFORE OVERFILLING.



5. CLEAN UP ANY SPILLED FLUIDS AND DISPOSE OF CLEANING MATERIALS OUTSIDE THE LIVING AREA .
6. STORE THE SIPHON PUMP OUTSIDE THE LIVING AREA WITH HANDLE IN UPWARD POSITION. REMOVE BATTERIES.

## CAUTIONS

1. **DO NOT** RUN DRY. ONLY SWITCH ON AFTER SUBMERGING THE BOTTOM OF PUMP IN KEROSENE.
2. **DANGER: DO NOT** USE WITH GASOLINE, PAINT THINNER, CHEMICAL SOLVENTS OR OTHER FLAMMABLE LIQUIDS. ACCEPTABLE FOR USE WITH NON-FLAMMABLE LIQUIDS SUCH AS KEROSENE, SOAPS, ETC.
3. WHEN USING WITH A KEROSENE HEATER-
  - \* ALWAYS TURN HEATER OFF AND ALLOW TO COOL BEFORE REFUELING.
  - \* FUEL HEATER OUTDOORS. CLEAN UP ANY SPILLS.
4. **DO NOT** LEAVE UNATTENDED DURING USE.
5. **DO NOT** TAPE THE BUTTON TO REMAIN IN THE "ON" POSITION.