

**LHC**  
**LAVISH HOME**  
 COLLECTION



**LIVE LOVE LAUGH DECAL LED FLAMELESS WAX CANDLE 3PC WITH REMOTE CONTROL/TIMER**

LED Candle sizes: 3" D; 4"/5"/6"H

**WARNING:** Do not mix old and new batteries. Do not mix alkaline, standard (Carbon-zinc) or rechargeable (Ni-Cd, Ni-Mh, etc.) batteries.

**BATTERY INSTALLATION**

Each candle requires 3 AAA batteries (Not Included)

1. Press the release tab and pull up to remove battery cover on bottom base.
2. Insert 3 AAA batteries into the battery compartment.  
Make sure to match the + and - signs to ensure proper operation.
3. Replace the battery cover.

**Remote Control:** Requires 1 CR2025 battery (Included)

1. Remove plastic tab to activate remote control.

**REMOTE CONTROL OPERATION 18KEY MODE**

ON/OFF	The candles can be turned on/off by simply pressing the "ON" or "OFF" button on the remote control.
COLOR	Press a specific color button and the candles will light in the corresponding color. 12 color options. If you would like to have another color setting on a candle, you need to move the remote control and candle at least 3 feet away from the other candles and press the color button.
MODE	Press "Mode" button, the light will flicker, press "Mode" button again, the light will be steady.
MULTI COLOR	Press "Multi Color" button for the lights to change color in continuous sequence.
4H or 8H	Timer function: <ol style="list-style-type: none"> <li>a. Pushing the "4H"/"8H" button sets candles to be lighted for 4/8 hours. After 20/16 hours, the light will turn off automatically. The candles will have light on again at the same time the following day.</li> <li>b. To reset the timer, switch the bottom of the candles to "OFF" position and repeat step1.</li> </ol>




FIGURE 1




FIGURE 2