



Parts List for LST140C Type 1

Item Number	Part Number	Description	Qty Required
1	90636575	HANDLE ASSEMBLY	1
2	90621578	TRIGGER	1
3	244053-00	SPRING, TRIGGER	1
4	90621579	LOCK OFF	1
5	90559867	COMPRESSION SPRING	1
6	90569937	SWITCH	1
7	90559876-01	COLLET ASSY.	1
8	90634406	TUBE ASSY	1
9	90554396-01N	BUTTON	1
10	90556608	BUTTON	1
11	90559866	SPRING	1
12	90639150	PCB ASSEMBLY	1
13	N498090	MOTOR & MOUNT	1
14	90636584	LEAD WIRE ASSY	1
16	90636582	MOTOR HOUSING	1
17	N498091	GEAR & SPINDLE	1
18	90626046	SPOOL & LINE	1
19	385022-03N	COVER	1
20	90566944	SPRING	1
21	330019-03	SCREW, PLASTITE	19
22	329301-00	CLAMP, CORD	1
23	373158	SCREW	2
24	90571331	EDGE GUIDE	1
25	90625191	HANDLE ASSY.	1
26	90567871N	GUARD ASSM.	1
28	90638112	RATING LABEL	1
29	90638113	LABEL	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for LST140C Type 1

Item Number	Part Number	Description	Qty Required
30	90567077	LEVER ASSEMBLY	1
866	LBX1540	BATTERY PACK	1
871	90604879-01	CHARGER	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.