
DOme



On/Off Plug-In Switch

Thank you for purchasing the DOME On/Off Plug-In Switch, which works with your Z-Wave Certified Controller to turn on and off any plugged in electronic device and monitor its power consumption.



Including/Connecting into the Z-Wave Network:

Follow the instructions for your Z-Wave certified Controller to enter inclusion mode.

When prompted by the Controller:

 For proper inclusion, bring the On/Off Plug-In Switch to within 10 feet of your Controller and plug it in. After inclusion, the device can be moved to any desired location.

2. Press the Connect Button quickly 3 times in a row. The LED Indicator will flash five times indicating inclusion.

Excluding/Disconnecting from the Z-Wave Network:

Follow the instructions for your Z-Wave certified Controller to enter exclusion mode.When prompted by the Controller:

- 1. Plug in the On/Off Plug-In Switch within range of your Z-Wave Controller.
- 2. Press the Connect Button quickly 3 times in a row.

The LED Indicator will flash five times indicating exclusion/disconnection.

Resetting the On/Off Plug-In Switch to Factory Default Settings:

To disconnect from the Z-Wave Network and restore factory default settings:

- 1. Plug in the On/Off Plug-In Switch.
- Hold the Connect Button for 10 seconds until the LED Indicator blinks once, then release the button.

Only do this if the controller is disconnected or otherwise unreachable!

Overload Protection:

The On/Off Plug-In Switch shuts off power and the LED Indicator will turn red when a current higher than 13 Amps passes through. To restore power after a current overload, power cycle the plug either by pressing the physical button or through your Z-Wave controller. You can also reboot the plug by unplugging it from the outlet.

Color	Meaning
No Light	Off
Green	On
Flashing Pink	Starting Up
Flashing Yellow	Inclusion/Exclusion
Solid Yellow	Max Current Threshold
Flashing Red	Current Overload
Solid Red	Error

NEED HELP? CONTACT DOME CUSTOMER SERVICE

If you have questions, our trained Customer Service Department is happy to assist you 24 hours a day, 7 days a week. Contact Dome Customer Service as follows:• In North America dial: 1-855-249-1754 • Email Dome at support@domeHA.com DO NOT RETURN THIS PRODUCT TO THE STORE OR WEBSITE FROM WHICH IT WAS PURCHASED If you believe the product is defective, has a missing or broken part or are having difficulty with it please contact Dome as listed above for a quick and efficient solution to the problem.

Legal Notices: This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna; increase the separation between the equipment and the receiver; connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.
 1 Year Limited Warranty
 Elexa Consumer Products, (nc. ("ECP") warrants to the original retail purchaser ("Purchaser") that the DOME Siren (the "Product")
 Elexa Consumer Products, (o Promac, 1153 Timber Dr., Elgin, IL 60123

 will be free of defects in materials or warship under use for one (1) year from th date of purchaser only, if the Product fails to or the Purchaser only, if the Product fails to
 Search and the Purchaser any request expedied return shipping at Purchaser's expose.

perform as specified during the Warranty Pe- THIS WARRANTY IS NOT TRANSFERABLE. riod due to defective parts or faulty workman- AND. TO THE MAXIMUM EXTENT PERMITship. ECP will repair or replace the defective TED BY APPLICABLE LAW IS IN LIEU OF ALL or damaged parts of the Product. Normal wear OTHER WARRANTIES, REPRESENTATIONS and tear is not covered nor is abnormal use, AND CONDITIONS, EXPRESSED OR IMPLIED. misuse. mishandling, faulty installation, im- STATUTORY OR OTHERWISE, INCLUDING BUT proper shipping, damage caused by disasters NOT LIMITED TO THE IMPLIED WARRANTIES such as fire, flood or earthquake, neglect, ac- OF MERCHANTABILITY AND FITNESS FOR A cident or tampering. This warranty covers only PARTICULAR PURPOSE, NO OTHER PERSON normal use in the United States or Canada. OR REPRESENTATIVE IS AUTHORIZED TO To obtain warranty service during the Warranty MAKE ANY OTHER WARRANTY ON BEHALE Period, call Dome Customer Service (1-855- OF ECP OR ASSUME FOR ECP ANY OTHER 249-1754) or email: support@domeHA.com for LIABILITY IN CONNECTION WITH THE SALE instructions on sending damaged parts and OF THIS PRODUCT. IN NO EVENT WILL ECP documentation for a Return Material Authori- BE LIABLE FOR ANY DAMAGES. INCLUDING zation (RMA). Products returned to ECP for re- BUT NOT LIMITED TO INCIDENTAL, SPECIAL pair or replacement without authorization will OR CONSEQUENTIAL DAMAGES ARISING OUT be returned at the sender's expense. All war- OF THE USE OR INABILITY TO USE THE PRODranty claims must be accompanied by a legible UCT, INCLUDING DAMAGES DUE TO ECP'S copy of the original receipt showing date and NEGLIGENCE.

details of purchase. The RMA number must THIS WARRANTY GIVES YOU SPECIFIC LEGAL be clearly written on the side of the shipping RIGHTS, AND YOU MAY ALSO HAVE OTHER container in which you return the Product or RIGHTS WHICH VARY FROM STATE TO STATE defective parts. Unless otherwise instructed by ECP, the Product must be sent freight pre-paid to the following address:

CORRECT DISPOSAL OF BATTERIES IN THIS PRODUCT


This marking on the product, accessories or literature indicates that the product and its electronic accessories should not be disposed of with other household waste.

To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate these items from other types of waste and recycle them responsibly to promote the sustainable reuse of material resources.

Household users should contact either the retailer where they purchased this product, or their government office, for details of where and how they can take these items for environmentally safe recycling.

Business users should contact their supplier and check the terms and conditions of the purchase contract. This product and its electronic accessories should not be mixed with other wastes for disposal.

This marking on the battery, manual or packaging indicates that the batteries in this product should not be disposed of with other household waste. Where marked, the chemical symbols Hg. Cd or Pb indicate that the battery contains mercury, cadmium or lead above the reference levels in EC Directive 2006/66. If batteries are not properly disposed of, these substances can cause harm to human health or the environment.



©2016 Elexa Consumer Products, Inc. 2275 Half Day Rd., Suite 333 Bannockburn, IL 60015



www.domeHA.com