


HAMPTON BAY®

USE AND CARE GUIDE

HARMONY COVE 4PC SLING DEEP SEATING SET - BLUE



Questions, problems, missing parts? Before returning to the store,
call Hampton Bay Customer Service.
8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday

1-855-HD-HAMPTON

HAMPTONBAY.COM

THANK YOU

We appreciate the trust and confidence you have placed in Hampton Bay through the purchase of this set. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Hampton Bay!

Table of Contents

Table of contents	2	Pre-assembly	3
Important Safety Instructions	2	Planning assembly	3
Save These Instructions	2	Hardware included	3
Read All Instructions Before Use	2	Chair Package contents	4
Warranty	3	Table Package contents	5
What is Covered	3	Loveseat Package contents	6
What is Not Covered	3	Chair Assembly	7
		Table Assembly	11
		Loveseat Assembly	13
		Care and Cleaning	16

Important Safety Instructions

SAVE THESE INSTRUCTIONS



WARNING: This set was as made for the explicit purpose of providing outdoor functions and is not to be used as a toy. This product is intended for normal outdoor use; however, the manufacturer recommends storing and / or covering this product when any formidable / severe weather is approaching.



WARNING: Do not locate this product near open flames. Do not use this product as a support. Do not shake, lean or climb on the product. Children under the age of 10, near the product, should be supervised by a competent adult at all times. This product is NOT intended for commercial use and will void the warranty.

READ ALL INSTRUCTIONS BEFORE USE

To reduce the risk of injury to persons:

1. Close supervision is necessary when this product is used by or near children, or disabled persons, if applicable.
2. Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.
3. Do not move the chair while it is occupied. Failure to obey this caution could result in injury.



CAUTION: When not in use, secure the product in a cool and covered location.



CAUTION: Do not locate the product near any heat sources.



WARNING: Weight limit for the chair is 250lbs (113.39Kg) for each seat.



WARNING: Please keep children out of the assembly area before assembly.



WARNING: This chair/ table unit is heavy, and may require two adults for safe assembly.



WARNING: Never use this product as a support. Do not shake, lean, or climb on the product at any time.



WARNING: Do not place heavy objects on the chair or table.

Warranty

2 YEAR FRAME WARRANTY

WHAT IS COVERED

We warrant the frame to be free of manufacturing defects to the original purchaser for two years.

WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center. This warranty does not cover commercial use, hardware, acts of nature, fire, freezing and abusive use. In addition, purchased parts are not covered under this warranty. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

Contact the Customer Service Team at 1-855-HD-HAMPTON or visit www.Hamptonbay.com

Pre-Assembly

PLANNING ASSEMBLY

Read all instructions before assembly.

To avoid damaging this product, assemble it on a soft, non-abrasive surface such as carpet or cardboard.







NOTE: More than one person may be required to assemble this product.

HARDWARE INCLUDED




NOTE: Hardware not shown to actual size.



Part	Description	Quantity
AA	M6x20 combination bolt	30+1
BB	M8x50 combination bolt	8+1
CC	Hex wrench	1
DD	Wrench	1

Pre-Assembly (continued)


CHAIR PACKAGE CONTENTS



Part	Description	Quantity
A	Right leg	2
B	Left leg	2
C	Chair seat	2
D	Chair back	2

Pre-Assembly (continued)


TABLE PACKAGE CONTENTS



Part	Description	Quantity
G	Table top	1
H	Table leg	4

Pre-Assembly (continued)

LOVESEAT PACKAGE CONTENTS



Part	Description	Quantity
A	Right leg	1
B	Left leg	1
E	Loveseat seat	1
F	Loveseat back	1


Chair Assembly

1 ATTACH THE CHAIR SEAT TO THE CHAIR BACK

- Place the chair back (D) upside down on a soft surface.
- Attach the chair seat (C) to the chair back (D) using M6x20 combination bolts (AA).



NOTE: Loosely tighten the bolts using the hex wrench (CC).




Chair Assembly (continued)

2 ATTACH THE RIGHT ARM TO THE CHAIR SEAT AND CHAIR BACK

- Attach the right arm (A) to the chair seat (C) and chair back (D) using M6x20 combination bolts (AA).



NOTE: Loosely tighten the bolts using the hex wrench (CC).




Chair Assembly (continued)

3 ATTACH THE LEFT ARM TO THE CHAIR SEAT AND CHAIR BACK

- Attach the left arm (B) to the chair seat (C) and chair back (D) using M6x20 combination bolts (AA).

 **NOTE:** Loosely tighten the bolts using the hex wrench (CC).



Chair Assembly (continued)

4 TIGHTEN ALL BOLTS

- Once all of the bolts are in place, fully tighten all the bolts using hex wrench (CC).
- Turn the chair right side up.
- Ensure all connections are secure before use.




Table Assembly

1 CONNECTING THE TABLE LEG TO THE TABLE TOP

- Place the table top (G) upside down on a soft surface.
- Attach the table legs (H) to the table top (G) using M8x50 combination bolts (BB).



NOTE: Loosely tighten the bolts using the wrench (DD).





Table Assembly (continued)

2 TIGHTENING ALL BOLTS

- ☐ Once all of the bolts are in place, fully tighten all the bolts using wrench (DD).
- ☐ Turn the table right side up.
- ☐ Ensure all connections are secure before use.




Loveseat Assembly

1 ATTACH THE LOVESEAT SEAT TO THE LOVESEAT BACK

- Place the loveseat back (F) upside down on a soft surface.
- Attach the loveseat seat (E) to the loveseat back (F) using M6x20 combination bolts (AA).



NOTE: Loosely tighten the bolts using the hex wrench (CC).




Loveseat Assembly (continued)

2 ATTACH THE RIGHT ARM TO THE LOVESEAT SEAT AND LOVESEAT BACK

- Attach the right arm (A) to the loveseat seat (E) and loveseat back (F) using M6x20 combination bolts (AA).



NOTE: Loosely tighten the bolts using the hex wrench (CC).




Loveseat Assembly (continued)

3 ATTACH THE LEFT ARM TO THE LOVESEAT SEAT AND LOVESEAT BACK

- Attach the left arm (B) to the loveseat seat (E) and loveseat back (F) using M6x20 combination bolts (AA).




NOTE: Loosely tighten the bolts using the hex wrench (CC).



Loveseat Assembly (continued)

4 TIGHTEN ALL BOLTS

- Once all of the bolts are in place, fully tighten all the bolts using hex wrench (CC).
- Turn the loveseat chair right side up.
- Ensure all connections are secure before use.



Care and Cleaning

- For best results, clean the frame with a damp cloth and dry thoroughly. This will help prevent mildew by removing dirt particles that may accumulate.
- Do not clean with abrasive materials, bleach, or solvents.
- Store the set in a dry, sheltered place when not in use.
- Keep the set away from fire, extreme heat, freezing conditions, and inclement weather such as rain, hail, sleet, snow, or wind.

HAMPTON BAY[®]

Questions, problems, missing parts? Before returning to the store,
call Hampton Bay Customer Service.
8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday

1-855-HD-HAMPTON

HAMPTONBAY.COM

Retain this manual for future use.

For certification use only
Factory chair ID # FCS60637
Factory table ID # FTS61326
Factory loveseat ID # FCS60637L