


INSTRUCTIONS FOR YOUR 13' COTTON ROPE HAMMOCK – Model 4902C

INSTALLATION AND USE:

Your cotton rope hammock is ready for use. There is no hanging hardware included with this unit. It may be hung between two secure upright posts or trees, or may be used with a hammock stand. Two trees or posts must be at least 15 feet apart. We recommend a bowline knot (see illustration) when tying down ends along with heavy, durable rope or cord.


Step 1



Step 2



Step 3



BOWLINE KNOT

Natural Effects of Weathering from Sun and Rain Exposure:

Any cotton, wood, and/or metal products will deteriorate over time with exposure to the elements. As a result, they should be regularly inspected and replaced periodically to ensure safety. Keep hammock out of direct sunlight and rain whenever possible. The more your hammock is subjected to direct sunlight and rain the sooner the following will occur:

- **Cotton Ropes:** Strength will be lost, and may mildew if in kept in a shady damp area.
- **Wood:** Wood spreader bars on hammock will become bleached and may turn gray. Varnish finish may wear off surface.
- **O-Ring:** There is a chance for excessive rust when consistently exposed to rain, moisture, or water.

Check before each use (Do not use if you find any of the following issues):

- Loose or untied ropes.
- Fraying at possible wear points:
 - Where the ropes pass through the wooden spreader
 - Around the metal ring at each end of the hammock
 - Where the ropes intersect in the body/hammock bed.
- Weak and fraying ropes: Check ropes by pulling on them. If ropes are weak, the hammock may be unsafe for further use.
- Cracks or weak areas in the wood.

Warnings:

- Maximum weight capacity is 300 lbs. **NEVER** exceed weight capacity.
- Children should not use the hammock without adult supervision.
- Always inspect the hammock and ties carefully before each use.
- Examine the entire hammock for wear to avoid accidents.
- Hammocks are designed for leisure and relaxation. It should not be used as a toy or a swing. Do not stand in the hammock at any time.
- Your hammock's worst enemies are rain, sun and heat. To prolong the life of your hammock, store it in a safe dry place when not in use. You may also choose to purchase a hammock storage bag, or cover with water resistant tarp when not in use.

Warranty:

Algoma Net Company products have a one year warranty to be free of defects in workmanship and. Obvious exposure to weather conditions including rain, snow, and humidity are not covered under this warranty. Other damage not covered under the warranty includes mildew, damaged caused by normal wear, improper care during storage, improper maintenance, damage from pets or other animals, and improper installation.

For Customer Service, Please Contact:
THE ALGOMA NET COMPANY, Div. of Gleason Corp.
1525 Mueller Street
Algoma, WI 54201
Phone: (920) 487-5577 / Fax: (920) 487-2852
Email: algomasales@algomanet.com

