

Use and Care for Fire Baskets

Do not touch fire basket until fire has been completely extinguished and fire basket has been allowed to cool to the touch. Remove ashes and unburned wood. Do not leave fire basket exposed to extreme elements.