


# Quick start guide

For RC / MC Models



**Follow me!**




**Robomow<sup>®</sup>**  
*friendly home*


Watch the Video



# Wire Setup


Chapter numbers mentioned in this Guide refer to the Operating & Safety Manual

 Carefully read and review all safety instructions, warnings and cautions contained in the Operating & Safety Manual.




## 1 What Does Your Lawn Look Like?

Chap. 3.1



## 2 Base Station Location

Chap. 3.2




## 3 Wire Direction & Distance

Chap. 4.2.1



## 4 Corners

Chap. 4.2.2



## 5 Obstacles Inside Lawn

Chap. 3.4.1




# Base Station Installation


**6** Finish  
Chap. 4.5




**7** Connect the Plot Connector  
Chap. 4.6



**8** Insert 2 Pegs  
Chap. 4.6




# Power Box Installation



**9** Chap. 4.6



**10** Chap. 4.7



**11** Chap. 4.7




# One-Time Setup


**12** Turn Safety Switch ON




**13** Operating Panel  
Chap. 5.2.1




**14** Choose Measurements Units  
Chap. 5.2.2



**15** Set Day & Time  
Chap. 5.2.3



**16** Set Lawn Size  
Chap. 5.2.4



**17** Test Base Station Position  
Chap. 5.2.5




Possible Error Messages:



**18** Peg Base  
Chap. 5.2.5




**19 Test Wire Position**  
Chap. 5.2.6




Possible Error Messages:

**U052** → Adjust wire



**20 Add Pegs**  
Chap. 5.2.7



# Reference

**21 Set Cutting Height**  
Chap. 5.1



Safety Switch off



**Sharp Blade**


LOW



HIGH



Cutting Height Indicator



DOC7002C

**For all RS models:**

- AT. 01/ 278 51 00-180
- BE. 070.660.124\*\*
- CH. 0900.888.101\*
- CZ. 800.909.898
- DE. 02421/ 693 76-80
- DK. 70 25 23 03
- FI. 093 157 9150
- FR. 03.68780407
- IE. 0862 550801
- IT. 840.22.22.00
- LU. 0900.4300.4090\*\*
- NL. 0900.762.6669\*\*
- NO. 4000.7719
- PL. +48 58 770 94 45
- RU. +7(495)544.24.14
- SE. 0771 895 895
- UK. 01522 283007

**For all MS models:**

- AT. 01/ 278 51 00-180
- BE. 070.660.124\*\*
- CH. 0900.888.101\*
- CZ. 800.909.898
- DE. 02421/ 693 76-80
- DK. 70 25 23 03
- FI. 093 157 9150
- FR. 03.68780407
- IT. 840.22.22.00
- LU. 0900.4300.4090\*\*
- NL. 0900.762.6669\*\*
- NO. 32 82 99 40
- PL. +48.58.770.94.45
- SE. 08 5250 8480
- UK. 014835 16633

\* 0-5 Min.= CHF 0.08/Min. ab/à partir de 6 Min.= CHF 1.40/Min. beim schweizerischen Festnetz. Pour le téléphone fixe Suisse Mobilfunkkosten können abweichen/Les coûts téléphoniques mobiles peuvent dévier.  
\*\* Max € 0.35 p/m.



robomow.com f