

Item #1000 000 000
Model #HOUC3603B1QWK




USE AND CARE GUIDE

36 IN. -3 DRAWER TOOL CART WITH WOOD TOP

Questions, problems, missing parts?
Before returning to the store, call
Husky Customer Service
8 a.m - 6 p.m., EST, Monday-Friday

1-888-43-HUSKY

HUSKYTOOLS.COM



THANK YOU

We appreciate the trust and confidence you have placed in Husky through the purchase of this chest/cabinet. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Husky!

Table of Contents

Table of Contents.....	2	Assembly.....	6
Safety Information.....	2	Operation.....	8
Warranty.....	3	Maintenance.....	9
Pre-Assembly.....	4	Care and Cleaning.....	9
Tools Required.....	4	Service Parts.....	10
Hardware Included.....	4		
Specifications.....	4		
Package Contents.....	5		

Safety Information

1. Do not open more than one drawer at a time.
2. Do not let children approach the tool cart.
3. Keep the locking casters brake set unless you are moving the cart. This will help to prevent the product from rolling.
4. Lock all drawers before moving the cart.
5. Do not step in the tray.
6. Do not pull the tool cart, push it when moving.
7. Do not alter this product in any manner.



DANGER: Do not stand on this product. You may fall or cause the product to tip.



DANGER: Do not move the product prior to closing and locking all the drawers. The drawers could come open and make the product unstable and tip.



DANGER: Do not mount this product on a truck bed or any other moving object.



WARNING: Keep the product on a level surface. The product may become unstable and tip if stored or moved on an uneven surface.



CAUTION: Do not lift this product directly with a forklift or tow with any mechanical devices.



CAUTION: Do not exceed the maximum product weight, including contents. Do not exceed the maximum weight for each drawer. See Specifications on page 4.



CAUTION: Only transport this product when empty. Properly secure when transporting.

Warranty

The manufacturer warrants the product to be free from defects in materials and workmanship for a period of three (3) years from date of purchase. This warranty applies only to the original consumer and only to products used in normal use and service. If this product is found to be defective, the manufacturer's only obligation, and your exclusive remedy, is the repair or replacement of the product at the manufacturer's discretion, provided that the product has not been damaged through misuse, abuse, accident, modifications, alteration neglect or mishandling. This warranty shall not apply to any product that is found to have been improperly installed, set-up, or used in any way not in accordance with the instructions supplied with the product. This warranty shall not apply to a failure of the product as a result of an accident, misuse, abuse, negligence, alteration, faulty installation, or any other failure not relating to faulty material or workmanship. This warranty shall not apply to the finish on any portion of the products such as surface and/or weathering, as this is considered normal wear and tear.

The manufacturer does not warrant and specifically disclaims any warranty, whether express or implied, of fitness for a particular purpose, other than the warranty contained herein. The manufacturer specifically disclaims any liability and shall not be liable for any consequential or incidental loss or damage, including but not limited to any labor/expense costs involved in the replacement or repair of said product.

Contact the Customer Service Team at 1-888-43-HUSKY or visit www.huskytools.com.

Pre-Assembly

TOOLS REQUIRED



Phillips
screwdriver



Safety
goggles




13 mm
Wrench

HARDWARE INCLUDED




NOTE: Hardware not shown to actual size.



AA



BB



CC

Part	Description	Quantity
AA	Screw M6x12L	32
BB	Washer M8	16
CC	Bolt M8x20L	16

SPECIFICATIONS


Maximum capacity (drawers)	150 lbs.
Empty weight	77 lbs.
Maximum product weight, including contents	500 lbs.



NOTE: Begin product assembly close to the final intended location of your tool cart. This product is heavy and may be difficult to move after assembly.

Pre-Assembly (continued)

PACKAGE CONTENTS



Part	Description	Quantity
A	Wood top	1
B	Side handle	1
C	Legs	4
D	Swivel caster with brake	2
E	Tray	1
F	Drawer slide (pair)	3

Part	Description	Quantity
G	Rigid caster	2
H	Key (set)	1
I	Drawer	3
J	Lock	2
K	Husky badge	1

Assembly

1 Installing the legs


- Ensure all cabinet drawers are securely locked into place using the lock (J) on the cart.
- Lay the cart upside down. Use the packaging material to protect the wood top from damage during assembly.
- Mount the four legs (C) to the cart using six screws (AA) per leg. Do not install four of the screws (AA) in the legs of the tool cart on the side adjacent to the Husky badge (K). The side handle (B) will be mounted here in a later step.



NOTE: The holes in the tool cart are tapped and do not require nuts.




NOTE: Two people may be required to complete this step.



2 Attaching the tray

- Clip the tray (E) to the four legs (C).




3 Securing the tray



NOTE: The holes in the tool cart are tapped and do not require nuts.

- Secure the tray (E) to the legs (C) using two screws (AA) per leg.




4 Installing the casters



CAUTION: Do not over tighten the bolts.

- Mount the two swivel casters with brake (D) to the tray (E) using four bolts (CC) and washers (BB) per caster. The swivel casters with brake (D) should be installed on the same side as the Husky badge (K).
- Mount the two rigid casters (G) to the tray (E) using four bolts (CC) and washers (BB) per caster.
- Tighten all bolts with a 13 mm wrench.
- Carefully return the tool cart to its upright position.




Assembly (continued)

5 Attaching the side handle



NOTE: The holes in the tool cart are tapped and do not require nuts.

- Attach the side handle (B) to the tool cart using four screws (AA).




Operation

1 Locking and unlocking the unit




IMPORTANT: The drawers must be fully closed before locking / unlocking the unit.

- Insert the key (H) into the lock and turn it fully to the left to lock.
- Remove the key (H).
- Insert the key (H) into the lock and turn it fully to the right to unlock.
- Remove the key (H).




2 Removing the drawers

- Fully extend and empty the drawer.
- Depending on the slide, either lift or lower the release lever on both sides so the slides can ride over the stops. Pull out to remove.



3 Installing the drawers


- Pull the slides and slide carrier out until fully extended.
- Hold the slide on the cabinet while aligning it with the slide on the drawer.
- Slightly insert one side and repeat for the other side.
- Slowly push the drawer until it is fully closed to engage the slide.
- Open the drawer and close it to verify proper operation.



Maintenance


1 Maintaining the casters

- Grease the casters annually using high quality bearing grease.



2 Maintaining the drawers


- Periodically clean the drawer trim, and inside the drawers with a mild detergent and water.
- Remove grease and oil with a standard, nonflammable cleaning fluid.
- The use of drawer liners is recommended to protect the finish inside the drawers and make the drawers easier to clean. Drawer liners can be purchased at The Home Depot and can be cleaned with soap and water.
- Lubricate the slides semi-annually with grease or equivalent.



Care and Cleaning

- This steel product has been coated with industrial powder coating for a durable finish.
- To help protect the powder coated finish, do not allow harsh chemicals (oil, grease, or other chemical) to remain on the powder coating surface.
- Use a glass cleaner (Windex[®] or equivalent product) to clean and maintain all surfaces of powder coating.
- The wood top is made of Parawood (also called Rubberwood) which has a polyurethane coating to help protect it from moisture. It can be cleaned with most household cleaners, such as Windex[®].

Service Parts



Part	Description	Quantity
A	Wood top	1
B	Side handle	1
C	Leg	4
D	Swivel caster with brake	2
E	Tray	1
F	Drawer slide (pair)	3
G	Rigid caster	2
H	Key (set)	1
I	Drawer	3
J	Lock	1
K	Husky badge	1



Questions, problems, missing parts? Before returning to the store, call
Husky Customer Service
8 a.m. - 6 p.m., EST, Monday-Friday

1-888-43-HUSKY

HUSKYTOOLS.COM

Retain this manual for future use.