




# Replacement Parts List

Touchless Single-Handle Pull-Down Sprayer Kitchen Faucet  
with LED Light in Chrome

MODEL	SKU #	FINISH
67536-1001	205591729	Chrome



Many replacement parts can be purchased online or at your local store. Please use the table below to identify the part SKU number needed, go to [HOMEDEPOT.COM](http://HOMEDEPOT.COM), and check for online and store availability. If you can't find the part you are looking for, please call 1-855-HD-GLACIER.

Part	Description	Part #	Internet SKU #	Store SKU #
1	Spray head and Hose	RP3822301		
2	Wearable ring	RP70380		
3	O-ring	RP60071		
4	Cartridge	RP20005	<a href="#">207093806</a>	
5	Bonnet	RP70394		
6	Cap	RP8002801		
7	Handle	RP1336801		
8	Screw	RP50015		
9	Index & O-ring	RP8044001		
10	Rubber washer	RP64087		
11	Metal washer	RP64088		
12	Nut	RP56098		
13	Protective cap	RP70448		
14	Block	RP70421	<a href="#">207093811</a>	
15	O-ring	RP60002		

Part	Description	Part #	Internet SKU #	Store SKU #
16	Quick connect assembly	RP70482	<a href="#">207093811</a>	
17	O-ring	RP60089		
18	Weight clip	RP64204	<a href="#">207093823</a>	
19	Weights	RP70441		
20	Escutcheon	RP8044101		
21	Bolt	RP50071		
22	Base plate	RP80442		
23	Mounting nut	RP56036		
24	Control box	RP70515	<a href="#">207093817</a>	
25	Battery pack	RP70514	<a href="#">207113905</a>	
26	Pump kit	RP46022		
27	Flange kit	RP4606601		
28	Bottle	RP46060		
29	Soap dispenser	RP4606501		