USE AND CARE GUIDE

SHANGHAI DARK GREEN UMBRELLA



Questions, problems, missing parts? Before returning to the store call Royal Garden Customer Service.

6 a.m. - 9 p.m., EST, 9 a.m. - 5 p.m., PST, Monday - Friday

(866) 988-3300

WWW.ROYALGARDEN.COM

THANK YOU

Table of Contents

Table of Contents	2
Safety Information	2
Product Caution	2
Safety Warning	2
Warranty	2
What is Covered	
What is Not Covered	2

Pre-Assembly	
Planning Assembly	3
Package Contents	3
Assembly	4
Operation	5
Care and Cleaning	7

Safety Information

PRODUCT CAUTION

This umbrella was made for the explicit puropse of providing outdoor functions and is not to be used as a toy. This product is intended for normal outdoor use; however, the manufacturer recommends storing and / or covering this umbrella when any formidable / severe weather is approaching. Do not locate the product near open flame. Do not use as a support. Do not shake, lean, or climb on product. Children under the age of 10, near the product, should be supervised by a competant adult at all times. This product is not intended for commercial use and will void the warranty.

SAFETY WARNINGS



WARNING: Please keep children out of the assembly area before assembly.



WARNING: This umbrella unit is heavy, and may require two adults for safe assembly.



CAUTION: Never use the umbrella in high wind conditions. Damage to the umbrella can occur.



CAUTION: Keep all flame and heat sources away from this product at all times.

Warranty

1 YEAR FRAME AND FABRIC WARRANTY

WHAT IS COVERED

We warrant the frame and fabric to be free of manufacturing defects to the original purchaser for one year.

WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center. This warranty does not cover commercial use, hardware, acts of nature, fire, freezing and abusive use. In addition, purchased parts are not covered under this warranty. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

Contact the Customer Service Team at (866) 988-3300 or visit WWW.ROYALGARDEN.COM

Pre-Assembly

PLANNING ASSEMBLY


Read all instructions before assembly.

To avoid damaging this product, assemble it on a soft, non-abrasive surface such as carpet or cardboard.



NOTE: More than one person may be required to complete the assembly of this product.

PACKAGE CONTENTS




Part	Description	Quantity
Α	Sunshade	1
В	Pole	1

Assembly

1 Assembling the umbrella shade to the umbrella pole


Push the button on the pole (B), insert the pole (B) into the sunshade (A). Then release the button until it clicks.



Operation

1 Opening the umbrella


 $\ \square$ To open the umbrella, slowly turn the crank located on the sunshade (A) in a clockwise direction.



Operation (continued)

2 Tilting the umbrella


 $\hfill\Box$ Click on the button on the umbrella pole to adjust the canopy to desired tilt.



Operation (continued)

3 Closing the umbrella

□ To close the umbrella, slowly turn the crank located on the sunshade (A) in a counter-clockwise direction.



Care and Cleaning

- For best results, clean the pole with a damp cloth and dry thoroughly. This will help prevent mildew by removing dirt particles that may accumulate.
- □ Do not clean with abrasive materials, bleach, or solvents.
- Clean the umbrella fabric with a mild soap and water mixture. Rinse thorouoghly with clean water and allow fabric to air dry completely.
- Always keep the umbrella closed when it is not in use.
- Keep the umbrella out of fire, extreme heat, freezing conditions, and inclement weather such as rain, hail, sleet, snow, or wind.

Questions, problems, missing parts? Before returning to the store call Royal Garden Customer Service.

6 a.m. - 9 p.m., EST, 9 a.m. - 5 p.m., PST, Monday - Friday

(866) 988-3300

WWW.ROYALGARDEN.COM

Retain this manual for future use.