


ENGRAVED ROSE PATTERN LED WAX ROUND CANDLE WITH REMOTE CONTROL 4.7"X3.7"



USE INSTRUCTIONS:

- 1. Remove plastic tab from Remote Control battery compartment.
- Install 3 AAA batteries (not included) into the battery compartment located on bottom base of candle. Make sure that the battery polarity (+/-) is as indicated. (see A)
- 3. Use the On-Off switch on the bottom of each candle to turn LED to the ON position. (see B)
- 4. Remote control functions:



INDOOR USE

This candle is for indoor use only, suitable to use as decorative light or night light.

This product is not a toy. Please keep it out of the reach of children.

Specifications

Material	wax+ plastic
Scent	Rose
LED Lifespan	50,000 hours
Candle Size	4.72" D x 3.74"H
Candle Net Weight	13.2ounces