CARE AND MAINTENANCE

Spot clean using a mild water-free solvent. Only a professional cleaner should undertake a complete overall cleaning.

The use of steam or water-based cleaners may cause excessive shrinking or staining.

NOTICE

- * Please make sure that you have all parts indicated before you begin assembly of this item
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly
- * This item may require periodic tightening

Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
1	Sofa Back		1X
2	Sofa Bottom		1X
3	Sofa&Chair Foot 1		3X
4	Sofa&Chair Foot 2		3X
5	Chair Back		2X
6	Chair Bottom		2X
7	Table Top		1X
8	Table Foot		4X
9	Table Top Glass	1-1-1	1X
А	Allen bolt(M6x28 mm)		32X
В	Flat washer	0	40X
С	Allen bolt(M6x35 mm)		8X
D	Allen key		1X




Model# FOX6006A / FOX6006B / FOX6006C FOX6006D / FOX6006E

ANAFI OUTDOOR LIVING SET

Product Dimensions:

25.6"x25.6"x27.6" H (Chair) 48" x 25.6"x27.6" H (Sofa) 35.4"x21.7"x13.8" H (Table)



ATTACH YOUR RECEIPT HERE

Serial	Number
--------	--------

PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 45 minutes.

Tools Required for Assembly (included): Allen Key

