


ITEM #000000000 MODEL #DS-24357

Use and Care Guide RIBBED URN

Operation


Using the Urn

- □ Always place the urn on a hard, level surface.
- □ Make sure the plant is planted in a pot with drainage holes prior to inserting the plant into the urn. The urn does not contain drainage holes.



Safety Information

□ This product is suitable for both indoor and outdoor use.



Care and Cleaning

Clean with a soft cloth, mild soap and water or a dust cloth. Do not use a scrub brush. If the paint chips, use paints and a brush to fix. If rust is showing, sand lightly and repaint the area with paints.

Warranty

This product carries no warranty.

For questions or concerns about this product, contact the Customer Service Team 8:00 a.m. to 5:00 p.m. EST at 1-877-527-0313 or visit www.HomeDepot.com.