



Item #1002 437 961
Model #DS05QRH

USE AND CARE GUIDE

BEDFORD KITCHEN CART



Questions, problems, missing parts? Before returning to the store,
call Hampton Bay Customer Service
8 a.m. - 7 p.m., EST, Monday-Friday, 9 a.m. - 6 p.m., EST, Saturday

1-855-HD-HAMPTON

HAMPTONBAY.COM

THANK YOU


We appreciate the trust and confidence you have placed in Hampton Bay through the purchase of this kitchen cart. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Hampton Bay!

Table of Contents

Table of Contents.....	2	Pre-Assembly	3
Safety Information.....	2	Planning assembly.....	3
Warranty.....	2	Hardware Included.....	3
What is Covered.....	2	Package Contents	4
What is Not Covered	2	Assembly	6
		Care and Cleaning	10

Safety Information

1. One or two people are required for this assembly.
2. Do wear safety gloves to protect your hands during assembly.
3. When assembling and using this product, basic safety precautions should always be followed to reduce the risk of personal injury and damage to equipment. Please read all instructions before assembly and usage.



CAUTION: Throw away the silica gel contained with this product. Do not eat.

NOTICE: NATURAL BEAUTY OF WOOD

Wood has a natural beauty & elegance that displays the distinctive characteristics of its original habitat signature grain.

From crisp yet rich tonal properties to intricate whorls representing unique fingerprint which has visible scars, cracks, grain related blemishes all combined with the uneven grain texture, color & shades.

As no two trees are the same, every piece of wood is unique with it's original characteristics of natural knots, cracks, marks, mineral stains, texture & hue. These are not to be considered defects but rather part of the natural characteristics and beauty of wood.

Warranty

1 YEAR WARRANTY

WHAT IS COVERED

This limited warranty is extended to the original purchaser and applies to defects in materials and workmanship of your item provided the item is maintained with care and used only for personal, residential purposes. The item is warranted to be free from defects in material or workmanship for a period of 1 year.

WHAT IS NOT COVERED

We do not reimburse for transportation of delivery costs, or compensate the individual or any outside party for assembling or disassembling the product.

Contact the Customer Service Team at 1-855-HD-HAMPTON or visit HAMPTONBAY.COM.

Pre-Assembly

PLANNING ASSEMBLY

Before beginning assembly of this product, make sure all parts are present. Compare parts with the Hardware Included and Package Contents lists. If any part is missing or damaged, do not attempt to assemble the product. Contact customer service for replacement parts.


HARDWARE INCLUDED




NOTE: Hardware not shown to actual size.



___AA



___BB



___CC




___DD



___EE



___FF



___GG



___HH



___II



___JJ



___KK



___LL




___MM


Label	Part Number	Description	Quantity	Additional hardware
AA	H06030C12	Bolt M6*30	4	1
BB	H08047K13	Screw M5*47	4	1
CC	H11030J12	Screw M4*30	16	4
DD	P90401A10000	Dowel Ø6*30	10	2
EE	H13001C12	Spring Washer M6	4	1
FF	H12001C12	Flat Washer M6	4	1
GG	P90101A01002	Cam Bolt M6*32	4	1
HH	P90101B01002	Cam Ø15*12	4	1
II	P90001A01004	Handle	1	0
JJ	H00002C13	Allen Key Size 4	1	0
KK	H09010A14	Bolt M4*10	2	0
LL	P90301A01002	Caster Wheel With Lock	2	0
MM	P90301B01002	Caster Wheel	2	0

Pre-Assembly (continued)


PACKAGE CONTENTS




____ #1




____ #2




____ #3




____ #4




____ #5




____ #6




____ #7




____ #8




____ #9




____ #10



____ #11



____ #12



____ #13

Pre-Assembly (continued)

Part	Part Number	Description	Quantity
#1	P12301A10011	Table top	1
#2	P21101A10011	Left panel	1
#3	P21101B10011	Right panel	1
#4	P21201A10011	Back panel	1
#5	P11701A10011	Upper shelf	1
#6	P11702A10011	Bottom shelf	1
#7	P02102A10011	Towel bar holder	2
#8	P02101A10011	Towel bar	1
#9	P21301A10011	Front drawer panel	1
#10	P21302A10011	Left drawer panel	1
#11	P21302B10011	Right drawer panel	1
#12	P21303A10011	Back drawer panel	1
#13	P21304A10011	Bottom drawer panel	1


Assembly

1 Inserting the Cam bolts

- Insert the Cam bolts (GG) in the Right panel (#3).



NOTE: To avoid destroying the finish, do not put the parts on the ground directly.




2 Assembling the Towel bar

- Connect the Towel bar holders (#7) with the Towel bar (#8).



NOTE: To avoid destroying the finish, do not put the parts on the ground directly.




3 Connecting the Towel bar

- Connect the assembled Towel bar holder (#7) with the right panel (#3) using Screws (BB). Tighten with Hex key (JJ).



NOTE: To avoid destroying the finish, do not put the parts on the ground directly.




4 Inserting the Cam bolts

- Insert the Cam bolt (GG) in the Left panel (#2).



NOTE: To avoid destroying the finish, do not put the parts on the ground directly.




Assembly (continued)

5 Attaching the Back panel and Upper shelf

- Attach the Back panel (#4) to the Left panel (#2) using Wooden pins (DD) and Screws (CC). Insert the Upper panel (#5) into the Cam bolts (GG) on the Left panel (#2) to connect with the panel. Secure together using the Cams (HH).



NOTE: To avoid destroying the finish, do not put the parts on the ground directly.




6 Attaching the Bottom shelf

- Insert the Wooden pins (DD) on the Left panel (#2), then connect the Bottom shelf (#6) with the Left panel (#2) using Flat washers (FF), Spring washers (EE) and Bolts (AA). Tighten with Hex key (JJ).



NOTE: To avoid destroying the finish, do not put the parts on the ground directly.




7 Attaching the Right panel

- Repeat step 5 and step 6 to attach the Right panel (#3).



NOTE: To avoid destroying the finish, do not put the parts on the ground directly.




8 Attaching the Caster wheels

- Insert the Caster wheels (LL&MM) on the bottom of the side panels (#2 & #3).



NOTE: To avoid destroying the finish, do not put the parts on the ground directly.




Assembly (continued)

9 Attaching the Table top

- ❑ Insert the Wooden pins (DD) on the side panel (#2 & #3), then place the Table top (#1) on the assembled body.



NOTE: To avoid destroying the finish, do not put the parts on the ground directly.




10 Securing the Table top

- ❑ Secure the Table top (#1) with the side panels (#2 & #3) using Screws (CC).



NOTE: To avoid destroying the finish, do not put the parts on the ground directly.




11 Attaching the Side drawer panel

- ❑ Connect the Side drawer panels (#10 & #11) with the Back drawer panel (#12) using Screws (CC).



NOTE: To avoid destroying the finish, do not put the parts on the ground directly.




12 Attaching the Bottom drawer panel

- ❑ Insert the Bottom drawer panel (#13) into the assembled drawer body.



NOTE: To avoid destroying the finish, do not put the parts on the ground directly.




Assembly (continued)

13 Attaching the Front drawer panel and the Handle

- Attach the Front drawer panel (#9) to the Side drawer panels (#10 & #11) using Screws (CC). Then attach the Handle (II) on the Front drawer panel (#9) using Bolts (KK).



NOTE: To avoid destroying the finish, do not put the parts on the ground directly.




14 Placing the Drawer

- Place the assembled drawer onto the chain and close it.



NOTE: To avoid destroying the finish, do not put the parts on the ground directly.



Care and Cleaning

- ☐ Before using, clean the cart completely with a soft dry towel.
- ☐ Clean the surface of the cart after use with a hot, soapy sponge.
- ☐ When not in use, store in a cool, dry area.



Questions, problems, missing parts? Before returning to the store,
call Hampton Bay Customer Service
8 a.m. - 7 p.m., EST, Monday- Friday, 9 a.m. - 6 p.m., EST, Saturday

1-855-HD-HAMPTON

WWW.HAMPTONBAY.COM

Retain this manual for future use.