




## Replacement Parts List

Nottely Touchless Single-Handle Pull-Down Kitchen Faucet in Chrome

MODEL	SKU #	FINISH
HD67495-1001	305514647	Chrome



Many replacement parts can be purchased online or at your local store. Please use the table below to identify the part SKU number needed, go to [HOMEDEPOT.COM](http://HOMEDEPOT.COM), and check for online and store availability. If you can't find the part you are looking for, please call 1-855-HD-GLACIER.

Part	Description	Part #	Internet SKU #	Store SKU #
1	Sprayhead and Hose	RP3840501		
2	O-ring	RP60071		
3	Wearable ring	RP70380		
4	Cartridge & Screw	RP20052		
5	Bonnet nut	RP70582		
6	Cap	RP8018401		
7	Handle assembly	RP1364101		
8	FastMount™	RP56096		
9	Escutcheon	RP8066701		
10	Gasket	RP80675		

Part	Description	Part #	Internet SKU #	Store SKU #
11	Block	RP70421	<a href="#">207093811</a>	
12	O-ring	RP60002		
13	Quick connect assembly	RP70482		
14	O-ring	RP60089		
15	Weight	RP70441		
16	Weight clip	RP70609		
17	Sensor control box	RP70650		
18	Battery pack	RP70514	<a href="#">207113905</a>	