



Grape Solar 100 Watt Basic Off Grid Kit (GS-100-BASIC) Quick Connect Guide

IMPORTANT: Please read the Panel User Manual (formerly titled the Safety & Installation Manual), the kit sizing guide (available at www.grapesolar.com/manuals.html) and the PWM-165 manual before following the steps in this guide.

TOOLS REQUIRED: wire cutter/stripper, phillips head screwdriver

Exclusion for Documentation

UNLESS SPECIFICALLY AGREED TO IN WRITING, SELLER

MAKES NO WARRANTY AS TO THE ACCURACY, SUFFICIENCY, OR SUITABILITY OF ANY TECHNICAL OR OTHER INFORMATION PROVIDED IN ITS MAN-UALS OR OTHER DOCUMENTATION;

ASSUMES NO RESPONSIBILITY OR LIABILITY FOR LOSSES, DAMAGES, COSTS OR EXPENSES, WHETHER SPECIAL, INDIRECT, CONSEQUENTIAL OR INDI-DENTAL, WHICH MIGHT ARISE OUT OF THE USE OF SUCH INFORMATION. THE USE OF ANY SUCH INFORMATION WILL BE ENTIRELY AT THE USER'S RISK; AND

REMINDS YOU THAT IF THIS MANUAL IS IN ANY LANGUAGE OTHER THAN ENGLISH, ALTHOUGH STEPS HAVE BEEN TAKEN TO MAINTAIN THE ACCURACY OF THE TRANSLATION, THE ACCURACY CANNOT BE GUARANTEED. APPROVED CONTENT IS CONTAINED WITH THE ENGLISH LANGUAGE
VERSION WHICH IS POSTED AT WWW.GRAPESOLAR.COM/MANUALS.HTML

Step 1: Check your order to make sure that all parts are included. For the GS-100-BASIC, this is:

- 1 pc GS-STAR-100W solar panel,
- 1 pc 15-foot MC4-comparable cable (to be cut in half),
- 1 pc red/black 5-foot bare-wire-to-ring-lug cable pair,
- 1 pc 10 amp inline fuse, and
- 1 pc Grape Solar PWM-165 charge controller.









Step 2: If you are connecting the system during daylight, cover the panel with cardboard, cloth, or a similar option so that it does not output power. Place the panel so it is facing due south at approximately the same angle as your latitude, in full sun.



©Copyright 2016, Grape Solar, Inc. All Rights Reserved

www.grapesolar.com Tel. 1-877-264-1014 (toll free), 1-541-349-9000, Fax: 1-541-343-9000






Grape Solar 100 Watt Basic Off Grid Kit (GS-100-BASIC) Quick Connect Guide

Step 3: Mount the controller if desired (note that it must be in a NEMA-4 rated enclosure if it is outdoors). Use the 5-foot red & black cable pair to connect your positive and negative battery terminals to the battery inputs on the charge controller.

Step 4: Attach the lug end of the red cable to the positive terminal on the battery. Attach the lug end of the black cable to the negative terminal on the battery (see photo, below left). If your battery has sufficient charge (11.5 volts or more), you should now see the controller's LCD display activate. This means the controller has power (controllers are powered by the battery, not the panels).



Step 5: Connect the positive MC4 output of the panel to the 10 amp inline fuse, as shown below:






Step 6: Cut the 15-foot MC4 cable into two equal halves (7.5 feet each). Strip back the wire on the cut end around 1/4 inch to expose the wire (see photos to right). Connect the MC4-comparable ends of the 7.5 foot wires to the panel leads. Follow the positive lead and mark the bare wire end of the 7.5 foot cable to differentiate it from the negative.



Step 7: Connect the bare wire end of the positive cable to the "Solar +" input of the PWM-165, and the other (negative) cable end to the "Solar -" input as shown to the right.





FOR ADDITIONAL INFORMATION, SEE: WWW.GRAPESOLAR.COM/MANUALS.HTML

Or email us at support@grapesolar.com

©Copyright 2016, Grape Solar, Inc. All Rights Reserved

www.grapesolar.com Tel. 1-877-264-1014 (toll free), 1-541-349-9000, Fax: 1-541-343-9000