USE AND CARE MANUAL

The care of wood furniture varies according to the wood type and finish and the function of the piece.

Please consult your sales associate for more specific care guidelines, as some collections have supplemental care instructions for long-term maintenance.

Wood is a natural material susceptible to climate and the elements. Avoid placing your furniture in highly humid or dry areas, such as directly next to air vents. Direct sunlight may slightly darken or lighten wood furniture.

Note: Based on frequency of use and storage, dining table leaves may change tone at a different rate than the table itself.

Dust with a dry, soft cloth.

Remove any soil buildup with a damp cloth and dry immediately.

Wipe spills immediately with a soft, dry cloth.

If water is left standing, white spots can occur but should dissipate over time.

Paste wax and 0000 steel wool can be used on a wax finish to remove surface scratches. Rub lightly over the entire surface then buff with a soft cloth.

Do not use harsh chemicals or abrasives on any finish. Always use coasters or trivets to prevent heat and water from having direct contact with wood surfaces.

Use felt pads on any displays or hard objects that are placed directly on the wood. Avoid contact with certain materials, such as rubber, which might react with the finish.

Wax or oil finishes may be renewed by rubbing a light application of a penetrating oil with fine steel wool and wiping with a clean, soft cloth to remove any excess oil.

Avoid contact with certain materials, such as rubber, which might react with the finish.

Wood Care Products

Finisher's Formula Natural Beeswax Polish

For use on all solid wood furniture. All-natural oil and beeswax formula is non-toxic and biodegradable.

Guardsman≈ Water Mark Remover

For use on any wood surfaces. Cotton cloth is specially treated with proprietary oils to quickly and easily erase water rings caused by moisture, minor blemishes and surface scratches, as well as latex paint and most permanent marker stains.