

ITEM #1000-000-000

1000-000-000

1000-000-000

1000-000-000

MODEL #FCS00015J

FCS00015J-BLUE

FCS00015J-GRN

FCS00015J-RED

Sling Stacking Chair Use and Care Guide


Operation

1 Using the Chair

- Always place the chair on a hard, level surface.



WARNING: Do not rock in the chair as you may fall and cause serious injury.



Care and Cleaning

- For best results, clean the frame with damp cloth, and dry thoroughly. This will help prevent mildew by removing dirt particles that may accumulate.
- Do not clean with abrasive materials, bleach or solvents.
- Store the chair in a dry, sheltered place when not in use.
- Keep the chair out of fire, extreme heat, freezing conditions, and inclement weather such as rain, hail, sleet, snow, or wind.

Warranty

1 YEAR WARRANTY

WHAT IS COVERED

We warrant the frames to be free of manufacturing defects to the original purchaser for one year.

WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center.

This warranty does not cover commercial use, hardware, acts of nature, fire, freezing, and abusive use.

In addition, purchased parts are not covered under this warranty. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

For questions or concerns about this product contact the Customer Service Team 8 a.m.- 6 p.m. EST Monday through Friday at 1-888-628-1888 or visit www.HomeDepot.com.

HOMEDEPOT.COM

Please contact 1-888-628-1888 for further assistance.