



Fabric Shades by Redi Shade Use & Care

Use:

To raise, secure pleats with two included clips. To lower, remove the clips to release the pleats.

Cleaning:

- Lightly dust and/or vacuum with upholstery attachment.
- Spot Cleaning- Lightly blot stain using sponge with soap or mild detergent and warm water. Fully open shade and allow to air dry. Entire shade can be cleaned this way if necessary.

Caution:

Full water immersion, dry cleaning, ultrasonic cleaning, spot remover, and strong detergent are not recommended.



Redi Shade Customer Service: 1-888-608-6611