

DECORATIVE GATE TEE HINGE AND LATCH SET







Juego de bisagra en T y pestillo decorativo para portón

EVERBILT

TM



SELF-LATCHING
Cierre automático



Ideal for outdoor gates or shed doors.
Features padlock hole for added security.
Working load limit per hinge: 50 lbs

INSTRUCTIONS:

To Install Hinge:

1. Place hinge straps on gate so that tee side of hinge hangs over side of gate. For adequate support, align hinge straps with horizontal gate supports.
2. Mark screw locations on gate and drill 9/64 in pilot holes.
3. Secure hinge straps to gate with screws.
4. Position gate at desired height to allow for adequate ground clearance (approximately 4 in from top and bottom of gate post).
5. Mark screw locations of tee side of hinge on gate post and drill 9/64 in pilot holes.
6. Secure tee side of hinge to post with screws.

To Install Latch:

1. With gate closed, align latch with center bar.
2. Mark screw locations and drill 3/32 in pilot holes for latch.
3. Secure latch with short screws.
4. Drill 7/64 in pilot holes for center bar and secure with long screws.

To Install Handle:

1. Position in desired location and mark screw holes.
2. Drill pilot holes using a 5/64 in drill bit.
3. Install and tighten screws.

For Outside Operation: Drill hole through post and attach a wire from the latch to a pull ring (not included).

Ideal para puertas en exteriores o de cobertizos.
Tiene orificio para candado y brinda así mayor seguridad.
Limite de carga por cada bisagra: 50 plg (22.7 kg)

INSTRUCCIONES:

Para Instalar la Bisagra:

1. Coloca las correas de la bisagra en la puerta de tal manera que el lado en T de la bisagra cuelgue de la parte lateral de la puerta. Para lograr un apoyo adecuado, alinea las correas de la bisagra con los soportes horizontales de la puerta.
2. Marca las ubicaciones para los tornillos en el portón y taladra orificios piloto de 9/64 plg (3.6 mm).
3. Fija las correas de la bisagra al portón con tornillos.
4. Coloca el portón a la altura deseada para dejar un espacio libre con respecto al nivel del piso (aproximadamente 4 plg (10.2 cm) del tope y la parte superior del poste del portón).
5. Marca las ubicaciones para los tornillos del lado en T de la bisagra en el poste del portón y taladra orificios piloto de 9/64 plg (3.6 mm).
6. Instala el lado en T de la bisagra en el poste con los tornillos.

Para Instalar el Pestillo:

1. Con la puerta cerrada, alinea el pestillo con la barra central.
2. Marca las ubicaciones para los tornillos y taladra orificios piloto 3/32 plg (2.4 mm) para colocar el pestillo.
3. Asegura el pestillo con tornillos cortos.
4. Taladra orificios piloto de 7/64 plg (2.8 mm) para colocar la barra central y asegúrala con tornillos largos.

Para Instalar el Tirador para Portón:

1. Colóquelo en la ubicación deseada y marque los orificios para los tornillos.
2. Perfore los orificios guía con una broca de 5/64 plg (2.0 mm).
3. Instale y ajuste los tornillos.

Funcionamiento desde el Exterior: Taladre un oricio que atraviese el poste y je un alambre desde el pestillo hasta el tirador (no incluido).