

INSTRUCTIONS FOR USE of the LEAF EASY™

- 1) Unfold to open and lie flat with logo up. Position the LeafEasy™ with the widest end up against the pile.
- 2) Rake onto top of the LeafEasy™. The LeafEasy™ holds enough debris to fill a 30 gallon yard bag in one scoop. *Only fill to your ability to lift.*
- 3) Position LeafEasy™ over the garbage can, angled side in, and pour.
- 4) For pruning: When pruning limbs and branches, or other larger lawn and garden debris, lay branches across the middle between the scored lines. Fold together and place entire LeafEasy™ in garbage bag, then slowly pull the LeafEasy™ upward to remove. *No more wrestling with the branches!*

HELPFUL HINTS

- 1) First time use: Push through the handles inward with fingers.
- 2) Convenient storage options.
- 3) To clean dirt and residue, spray with a hose. The LeafEasy™ is water safe.
- 4) *****ONLY FILL TO YOUR ABILITY TO LIFT UP COMFORTABLY*****

EASY AS 1-2-3



THANK YOU FOR YOUR INTEREST IN OUR PRODUCT! We welcome all feedback.

Please share your LeafEasy™ experience. Visit www.leafeasy.com for more information.