

Spun Glass Surfaces



For best results, keep the following in mind when caring for your KOHLER® product:

- Always test your cleaning solution on an inconspicuous area before applying to the entire surface.
 - Wipe surfaces clean and rinse completely with water immediately after applying cleaner. Rinse and dry any overspray that lands on nearby surfaces.
 - Do not allow cleaner to soak.
 - Use a soft, dampened sponge or cloth. Never use an abrasive material such as a brush or scouring pad to clean surfaces.
 - For warranty information call 1-800-4KOHLER (1-800-456-4537).
* Success with cleaners and procedures is dependent upon such factors as the hardness and temperature of the water, using exact measurements of ingredients, changes in cleaning formulas and the condition of the product being cleaned. Since there are variations within these factors, Kohler cannot guarantee the effectiveness of the formulas.
-

- Do not use bristle brushes, abrasive sponges or abrasive cleaners. They will scratch some glass surfaces.
- Do not let cleaners soak on surfaces.
- Rinse and wipe fixtures after cleaning to prevent soap buildup.

Success with cleaners and procedures is dependent upon such factors as the hardness and temperature of the water, using exact measurements of ingredients, changes in cleaning formulas and the condition of the product being cleaned. Since there are variations within these factors, Kohler cannot guarantee the effectiveness of the formulas mentioned.

Care Tip

To avoid lime buildup in hard water areas, make a point to wipe the product dry after each use, just as you would towel dry your hands with a soft cloth. To prevent scratching while cleaning, save old T-shirts or flannel nightgowns for great cleaning cloths.

Products to Consider

- Green Works Glass Cleaner
- Windex Original
- Mr. Clean with Febreze Freshness Antibacterial Spray